

Prokord Laptop Lock Single Head – Digit

Code Reset Instructions

Factory Code: 0000

To set a new code:

1. Locate the small screw on the back of the lock.
2. Turn the screw 90° clockwise.
3. Set your desired code by rotating the digit wheels.
4. Turn the screw 90° counterclockwise back to its original position.
5. Your new code is now set.

 Note: If the code is lost, the lock can no longer be opened.