


LCD TV

QUICK SETUP GUIDE

The Supplied Accessories

- Remote Control & Batteries (AAA x 2)
- Owner's Instructions
- Cleaning Cloth
- Power Cord



- Blanking Bracket




- Cable tie




(46 ~ 55 inch TVs)

- Holder-Ring (4ea)

See separate guide for installing the stand.



- Stand (1EA)




- Guide Stand (1EA)



- Screws (9EA)
(32 inch model only: 8EA)

Installing Batteries in the Remote Control



NOTE


- Use the remote control within 23 feet from the TV.
- Bright light may affect the performance of the remote control. Avoid using nearby special fluorescent light or neon signs.
- The colour and shape may vary depending on the model.




BN68-02747A-00

Installing the Stand


Preset



Step 1



Step 2



Preset: Place the Guide Stand and Cover Neck onto the stand and fasten it using the screws. Applicable to models (Depending on the model)

Step 1. Attach your LCD TV to the stand.

Two or more people should carry the TV.

Make sure to distinguish between the front and back of the stand when assembling them.

To make sure the TV is installed on the stand at a proper level, do not apply excess downward pressure to the upper left of right sides of the TV.


Step 2. Fasten two screws at position 1 and then fasten two screw at position 2.

Stand the product up and fasten the screws. If you fasten the screws with the LCD TV placed down, it may lean to one side.


Assembling the Cables

Enclose the cables in the Cable tie so that the cables are not visible through the transparent stand.

Overly rigid or thick cables can damage input jacks over long term use.




Using the remote control buttons



Plug & Play

When the TV is initially powered on, basic settings proceed automatically and subsequently. If you want to reset this feature, press the **MENU** button to display menu. You can set the Plug & Play by selecting **Setup** → **Plug & Play**.



On the screen, you can set as follows.

The each step may vary depending on the Antenna source.

Step 1

Plug & Play

Select the OSD Language.

Menu Language : English

Enter

Step 2

Plug & Play

Select the usage mode.

Store Demo Home USE

Previous Move Enter

Step 3

Plug & Play

Select Country.

Country : United Kingdom

Previous Enter

Step 4

Plug & Play

Antenna Source : Air

Channel Source : Digital & Analogue

Search

Previous Skip Move Enter

Step 5

Plug & Play

Auto Store in progress.

Channels 7

3%

Digital	TV:2	Radio:0	Data/Other:0
Analogue	0		

Stop

Enter

Step 6

Plug & Play

Set the Clock Mode.

Clock Mode : Auto

Previous Skip Enter

Step 7

HD Connection Guide

How to get the best performance from your new HDTV.

Step 1. Connect the HD Box to the TV using the HDMI or Component cables.

TV rear view >

HDMI Cable

Component Cable

Previous Skip Next Page

Step 8

Plug & Play

Enjoy your TV.

OK

★ ★ HD connection

Using an HDMI Cable

DVD / Blu-Ray player / HD Cable Box
/ HD Satellite receiver (STB)

HDMI OUT


★ ★ HD connection

Using a DVI Cable

DVD / Blu-Ray player / Cable Box
/ Satellite receiver (STB)

AUDIO OUT

DVI OUT



Audio/Video connection

Using an Audio/Video Cable

VCR

VIDEO OUT

AUDIO OUT

Component connection

Using a Component Cable

DVD / Blu-Ray player / Cable
Box / Satellite receiver

AUDIO OUT

COMPONENT OUT

Using a Scart Cable

VCR / DVD

EXT