



User Manual


WIRED GAMING KEYBOARD
DK-GR8R68-20

To use this device properly, please read the user's guide before installation.

1. Installing the keyboard

Connect the keyboard into an available USB port via the 1.8 meter USB cable. When connected all keycaps will be backlit and the computer will auto-search this device.

2. Key Features



1. Three LED indicators (Number-lock/ Capslock / Win-lock)
2. Separate Backlit mode selection button
3. 12 multimedia hotkeys with Fn, Convenient Volume Knob

3. Keyboard Hotkeys

Fn+F1	Media play
Fn+F2	Volume down
Fn+F3	Volume up
Fn+F4	Music
Fn+F5	Previous track
Fn+F6	Next track
Fn+F7	Play/puse
Fn+F8	Stop
Fn+F9	E-mail
Fn+F10	Homepage
Fn+F11	My computer
Fn+F12	Calculator

4. Illumination Control

4.1 Light adjustments

Fn+Arrow up	Backlit brightness up
Fn+Arrow down	Backlit brightness down
Fn+Arrow left	Decrease led wave speed
Fn+Arrow right	Increase led wave speed

4.1 Backlit mode selection



Press the "backlit mode selection" button to select one of the following 10 illumination modes

Mode 1	Fixed on	All keys backlit-on Mode(Default mode)
Mode 2	Gaming sepcial key	Gamer mode (default is FPS mode)
Mode 3	Delay off	Only the key-typed will be illuminated Press Fn+Del to switch led color
Mode 4	Neon stream	Wave Illumination from left to right Press Fn+Del to switch wave direction
Mode 5	Snake	Marquee mode Press Fn+Del to switch led color
Mode 6	Flash away	Backlit spread from the key-typed Press Fn+Del to switch led color
Mode 7	Flower	When you press one key, all keys around will be illuminated Press Fn+Del to switch led color
Mode 8	Rainbow	Illumination sparkling shifts from left to right Press Fn+Del to switch led color
Mode 9	Respire	Illumination apperas breathing Press Fn+Del to switch led color
Mode 10	Neonlight	Illumination switch between all 7 colors Fn + Esc, back to all key backlit-on mode

4.3 Professional gaming and programmer modes

Fn+1	FPS-mode	ASDW, arrows, ESC are illuminated
Fn+2	CF-mode	ASDW, Ctrl (left), Shift (left), Alt, Space, RGQEB, 1-5, Tab, F1-F3, Home, End, PgUp, PgDn, PrtSc, SCLK are illuminated
Fn+3	COD-mode	QWERTASDFGCV, 1-7, Ctrl (left), Shift (left) are illuminated
Fn+4	LOL-mode	QWERTASDF, 1-7 are illuminated
Fn+5	QQ race-mode	WRASD, Ctrl, Alt, Shift, arrow up, arrow down are illuminated

4.3.1 Color programming for professional

1. Press Fn + 1/2/3/4/5, to enter the Gamer mode
2. Press  to start color-program. Numlock/Caplock/Winlock backlit leds will start twinkling at the same time
3. Keep typing the keys (one by one) to choose the color you want
4. Press  again to finish the color program. Numlock/Caplock/Winlock backlit leds will go off

5. Lock/Unlock Windows-and App key

Press Windows + Fn, we can lock up the windows key and App keys, the Win-lock led will be on. Press again we can un-lock the windows key and App key, the Win-lock LED will be off.

6. Re-connecting

When this keyboard is re-connected to the Computer, the keyboard will memorize and recover back to the backlit mode of last time when use.