



Gates that Close Manually


















Gate Hub Installation Guide
















Gate Hub Installation Guide







Garage Position Sensor (Supplied by Gate Manufacturer)



Entrapment Protection Sensor (Supplied by Gate Manufacturer)






External Power (12-24 V, <1 A)






Internet

A



7



If you need further assistance, visit our Help Center or contact Ubiquiti Support.

Gate Hub Installation Guide

©2024 Ubiquiti Inc. All rights reserved. Ubiquiti, the Ubiquiti U logo, UniFi, and UniFi Access are trademarks or registered trademarks of Ubiquiti Inc. in the United States and in other countries. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. Apple Inc., registered in the U.S. and the Google Play logo are trademarks of Google LLC.