



Smart Home Sparepart Side Brush For W411-3

Data sheet

Summary

- ✓ Restores edge and corner cleaning performance for the W411-3 robot vacuum.
- ✓ Designed to reach along skirting boards and around furniture legs, improving overall cleaning coverage.
- ✓ Supplied as two side brushes to replace worn or damaged units and extend the life of the machine.
- ✓ Quick to fit and remove, so you can service the vacuum without tools.
- ✓ Check compatibility with your device model before purchase to ensure a correct fit.

Product description

Why choose this side brush?

Prokord Smart Home Sparepart Side Brush For W411-3 helps restore edge and corner cleaning on compatible robot vacuums. It improves debris pickup along walls and furniture, keeps cleaning cycles efficient, and provides a cost-effective way to maintain daily performance. The part is simple to install, reducing downtime for your cleaning routine.

Smart Home Sparepart Side Brush For W411-3 in short:

- Restores edge and corner cleaning performance for the W411-3 robot vacuum.
- Designed to reach along skirting boards and around furniture legs, improving overall cleaning coverage.
- Supplied as two side brushes to replace worn or damaged units and extend the life of the machine.
- Quick to fit and remove, so you can service the vacuum without tools.
- Check compatibility with your device model before purchase to ensure a correct fit.

Product details

These side brushes feature multiple flexible bristles arranged to sweep debris toward the vacuum intake. The Prokord Smart Home Sparepart Side Brush For W411-3 is intended as a direct replacement part for the W411-3, making it suitable for routine maintenance. You can swap worn brushes yourself in minutes to maintain consistent cleaning results and reduce the need for full-service interventions.

Technical Specification Matrix

Header

Manufacturer	Prokord
--------------	---------
