



Smart Home Robot Cleaner Accessory #kit

Data sheet

Summary

- ✓ Complete replacement set: main roller brush, HEPA-style filter, microfiber mop pad, and two side brushes.
- ✓ Restores pickup of dust, pet hair, and debris, improving cleaning efficiency.
- ✓ Microfiber mop pad refreshes wet-mopping performance on sealed hard floors.
- ✓ Easy to fit parts, so you can perform routine maintenance without tools.
- ✓ Check compatibility with your robot cleaner model before purchase.

Product description

Why choose this accessory kit?

Prokord Smart Home Robot Cleaner Accessory kit gives you a simple way to restore cleaning performance and extend the life of your robot cleaner. The set replaces worn brushes and filter elements so your device picks up dust and debris more reliably. It helps reduce maintenance time and maintains consistent results on both hard floors and low-pile carpets.

Prokord Smart Home Robot Cleaner Accessory kit in short:

- Complete replacement set: main roller brush, HEPA-style filter, microfiber mop pad, and two side brushes.
- Restores pickup of dust, pet hair, and debris, improving cleaning efficiency.
- Microfiber mop pad refreshes wet-mopping performance on sealed hard floors.
- Easy to fit parts, so you can perform routine maintenance without tools.
- Check compatibility with your robot cleaner model before purchase.

Maintenance and use

The Prokord Smart Home Robot Cleaner Accessory kit contains the wearable parts you replace most often. Swap the main roller and side brushes to improve hair and debris pickup. Replace the filter to reduce fine dust recirculation. Fit the microfiber mop pad when you need mopping function restored. These parts are intended for routine upkeep, helping you keep suction and cleaning results consistent over time.

Technical Specification Matrix

Header

Manufacturer	Prokord
--------------	---------
