



SETUP GUIDE

# VX-CAM500

# VX-CAM500

## MAIN INTERFACES & FEATURES



1. QHD 1440P OPTICAL LENS
2. OMNI DIRECTIONAL MIC
3. ONLINE STATUS LED
4. POWER STATUS LED
5. ROTATABLE JOINT
6. FLEXIBLE CLIP/BASE
7. METAL TRIPOD MOUNT
8. USB CABLE



# VX-CAM500

### DECIDING WHERE TO PLACE YOUR WEBCAM

DEPENDING ON YOUR COMPUTER SETUP, THEIA CAN BE SETUP TO PLACE/RECEIVE VIDEO CALLS

(A) ON A COMPUTER MONITOR

(B) ON YOUR DESKTOP

(C) ON ANY TRIPOD

### ON A COMPUTER MONITOR

AS ILLUSTRATED ON THE RIGHT, OPEN UP THEIA'S FLEXIBLE ARM AND HANG ON THE TOP OF YOUR MONITOR.

### ON YOUR DESKTOP

AS ILLUSTRATED ON THE RIGHT, CLOSE UP THEIA'S FLEXIBLE ARM AND PLACE IT ON YOUR DESKTOP.

### ON ANY TRIPOD

THEIA COMES WITH AN INDUSTRY STANDARD TRIPOD MOUNT FITTING MOST TRIPODS IN THE MARKET. CLOSE THEIA'S FLEXIBLE ARM AND TIGHTEN TRIPOD SCREW TO THE MOUNT.



# VX-CAM500

## INSTALLING PRIVACY LENS COVER



**FLIP OVER**

**REMOVE  
STICKER**

**THE PRIVACY LENS COVER  
COMES WITH ADHESIVE  
FOR INSTALLING OVER THE  
CAMERA LENS.**

**FLIP OVER THE COVER AND  
REMOVE THE WHITE STICKER  
PROTECTING THE ADHESIVE.**

**PLACE AND FIRMLY STICK  
LENS COVER OVER THEIA'S  
CAMERA LENS AS SHOWN.**

**FLIP OVER THE LID OF LENS  
COVER WHEN YOU NEED TO  
USE YOUR THEIA CAMERA.**



# VX-CAM500

## CONNECTING TO A COMPUTER

**CONNECT USB PLUG TO YOUR COMPUTER  
ANY USB TYPE-A (NOT TYPE C) PORTS OF  
YOUR DESKTOP/NOTEBOOK PC OR MAC  
SUPPORTS VX-CAM500 OUT OF THE BOX.**

**PLUG THE USB PLUG INTO ANY USB PORT  
AND WAIT A FEW SECONDS FOR DRIVERS  
TO LOAD AUTOMATICALLY. THERE IS NO  
NEED TO INSTALL ANY ADDITIONAL DRIVER  
OR SOFTWARE FOR VX-CAM500 TO WORK  
PROPERLY.**

**SOFTWARE SUPPORT & DEVICE DRIVER  
VX-CAM500 IS COMPATIBLE TO MOST  
VIDEO RECORDING OR VIDEO CONFER-  
ENCING SOFTWARES. HOWEVER, IT IS  
DESIGNED TO WORK PERFECTLY WITH ALL  
VERSIONS OF SKYPE, MICROSOFT TEAMS,  
CISCO WEBEX AND ZOOM.**


**SELECT UVC CAMERA AS VIDEO DEVICE.**



DO NOT PLACE OR STORE YOUR WEBCAM  
IN ANY HOT OR EXCESSIVELY HUMID PLACE.  
DO NOT CLEAN YOUR WEBCAM WITH ANY  
FORM OF CHEMICAL SUBSTANCE, ONLY USE  
WARM WATER. DO NOT TRY TO DISSEMBLE  
ANY PART OF THE WEBCAM EXCEPT  
REPLACING THE LENS COVER. DO NOT USE  
OR PLACE THE WEBCAM IN ENVIRONMENTS  
OF EXCESSIVE DUST OR MINUTE PARTICLES.



**WORKS WITH**



**WEB CLASSROOM  
VIRTUAL MEETING**



**LENS COVER**



**CE RoHS  
Compliant**