
Installing the Batteries

Wireless keyboard uses two AAA alkaline batteries


Install the Batteries in the Mouse

Step 1: Open the battery compartment.
Step 2: Insert the batteries as shown inside the battery compartment.



Install the batteries in the keyboard Step 1: Remove the battery compartment cover on the backside of the keyboard by squeezing the cover in from the tab to release it.


Step 2: Insert the batteries as shown inside the battery compartment.



The receiver is insert to USB port immediate, or by a extra USB cable.







1.Connect the USB plug to USB port of your computer

1

Abtain the receiver on the mouse

1:when you want use the mouse , you can take out the receiver to computer by the list \P step;

2:when you need stop the work or to travel, you can store the receiver on the mouse for the moving by the list 2 step.



Take out the receiver



Dpi shift function

Your optical 6 button mouse is provide 1000 & 1200 & 1600 dpi switch.



Power-Save function:

* This mouse is equipped with Traveling-Power-Save function. When you are traveling with this mouse, the LED of the mouse will be switched off automatically for the purpose of power-save, but the pre-condition is that the receiver is disconnected with your notebook or PC.

Your RF2.4Ghz mouse have a power safe mode. When your wireless mouse keeps unused for continuous 8 minutes, the mouse will come to deep sleep mode, the Optical LED will turn off, you should click any mouse button to wake up

2

Multim edia hotkeys functions:

Keyboard: 112 standard keys, 6 hotkeys

Homepage

Play/Pause

Volume+

Mute

Volume-Calculator Model: DMK-280WL



Instruction Manual

Wireless keyboard and mouse

