


VOXICON

VX-GS148M



Collapsible
Green Chroma-Key
Background




Details

Collapsible Green Chroma-Key Background 1pc


Ideal for even the tightest of workspaces, Green Screen assures a wrinkle-resistant, chroma-green surface. All you need to do is turn on some lights, take a seat, & work your creative magic. Works well no matter what it is you do, from twitch streamers to photography and everything in between. Green Screen sets the stage for truly immersive broadcasting in a matter of seconds.

Dimensions:


-1480 x 1800 mm / 58.27 x 70.87 in (screen)
-1645 x 105 x 115 mm / 64.76 x 4.13 x 4.53 in (retracted)





Instruction




1- Open the Legs 90° to secure the Background stability.




2- Open the security locks.



3- Lift the lever handle to pull up the Background.



4- Completely pull upwards & let the pneumatic X-frame automatically lock the screen in place.



5- Once you are done, pull up the lever a little bit and release it, And pack it up just as quickly as you set up.

Caution

1. Keep the screen far from the window & sun light, to prevent the screen from changing color.
2. When in use please to not touch the screen surface with fingers nor sharp object
3. The screen surface can be cleaned using a damp cotton cloth and wipe carefully
4. Handle the screen carefully to avoid any damage or distortion on both the case & stand