

# Yealink



Yealink Network Technology CO., LTD

**Yealink Camera-Hub Full HD Video Conferencing System**


Quick Start Guide(V1.0)

English | 简体中文


# Package Contents



Camera-Hub



USB3.0 to Ethernet  
Adapter




7.5m  
Ethernet Cable




Cable Tie×5



3m RCA to  
3.5mm Audio Cable



Power Adapter




Camera-Hub  
Quick Start Guide




We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in poor performance.

# Hardware Interface Instructions



- ① LED Indicator: indicate different status of the camera-hub.
- ② Reset: Reset the camera-hub to factory defaults.
- ③ USB Port
- ④ Camera Port
- ⑤ RCA In: connect to an audio input device via a RCA cable.
- ⑥ RCA Out: connect to the Soundbar via a RCA cable.
- ⑦ VC Hub/Camera: connect to the VCM34.
- ⑧ Internet: connect to the switch to connect UVC80s.
- ⑨ DC48V: connect to the power adapter.
- ⑩ Security slot: connect a universal security cable to the camera-hub so that you can lock the camera-hub down.


# Connections



- Do not connect the switch to the Internet, otherwise it will cause network abnormalities.
- The system should be used with Yealink original power adapter (48V/0.7A) only. The use of the third-party power adapter may damage the system. The cable should be replaced at once if its skin is broken.
- The switch and Ethernet cables should be purchased separately.



## Cable Ties Installation



## LED Indicator Instructions


LED indicators on the Camera-Hub:

LED Status	Description
Solid green	The Camera-Hub is active.
Solid red	The Camera-Hub is in sleep mode.
Solid orange	The Camera-Hub is initializing or upgrading the UVC80s.
Flashing orange	The Camera-Hub is upgrading firmware.


## 包装清单



Camera-Hub主机



USB3.0转RJ45  
转换头




7.5米网线




束线带 x5



3米 RCA转  
3.5mm音频线




电源适配器



快速入门指南


💡 我们推荐使用由Yalink提供或经Yalink认可的配件和线缆，使用未经认可的第三方配件和线缆可能会导致性能的下降。

## 硬件接口介绍




- ① 指示灯: 指示camera-hub的不同状态。
- ② 重置键: 重置设备到出厂设置。
- ③ USB接口
- ④ Camera接口
- ⑤ RCA In: 使用RCA音频线连接音频输入设备。
- ⑥ RCA Out: 使用RCA音频线连接Soundbar。
- ⑦ VC Hub/Camera: 连接VCM34。
- ⑧ Internet接口: 连接交换机以连接UVC80摄像机。
- ⑨ 电源接口: 连接电源适配器
- ⑩ 安全锁孔: 将主机锁在固定位置。

## 连接终端



- 💡 请勿将交换机接入Internet, 否则会引起网络异常。
- 💡 我们要求使用Yealink原装电源(48V/0.7A), 使用第三方电源可能会导致终端损坏。如果使用过程中发现线缆破皮, 请立即更换。
- 💡 交换机和相关网线需要另外购买。

## 使用束线带



## 指示灯介绍

Camera-Hub指示灯介绍如下:

指示灯状态	说明
绿灯常亮	Camera-Hub处于正常工作状态。
红灯常亮	Camera-Hub处于休眠状态。
橙色灯常亮	Camera-Hub处于启动/等待中状态,或处于升级UVC80状态。
橙色灯闪烁	Camera-Hub固件更新中。

## Regulatory Notices

### Operating Ambient Temperatures

- Operating temperature: +32 to 104°F (0 to 40°C)
- Relative humidity: 5% to 90%, noncondensing
- Storage temperature: -22 to +160°F (-30 to +70°C)

### Warranty


Our product warranty is limited only to the unit itself, when used normally in accordance with the operating instructions and the system environment. We are not liable for damage or loss resulting from the use of this product, or for any claim from a third party. We are not liable for problems with Yealink device arising from the use of this product; we are not liable for financial damages, lost profits, claims from third parties, etc., arising from the use of this product.

### Explanation of the symbols

#### ● DC symbol

⎓ is the DC voltage symbol.

#### ● WEEE Warning symbol

 To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

### Restriction of Hazardous Substances Directive (RoHS)

This device complies with the requirements of the EU RoHS Directive. Statements of compliance can be obtained by contacting support@yealink.com.

### Safety Instructions

Save these instructions. Read these safety instructions before use!

#### General Requirements

- Before you install and use the device, read the safety instructions carefully and observe the situation during operation.
- During the process of storage, transportation, and operation, please always keep the device dry and clean, avoid collision and crash.
- Please attempt not to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair.
- Please refer to the relevant laws and statutes while using the device. Legal rights of others should be respected as well.

#### Environmental Requirements

- Place the device at a well-ventilated place. Do not expose the device under direct sunlight.
- Keep the device dry and free of dusts.
- Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials.
- Keep the device away from any heat source or bare fire, such as a candle or an electric heater.

#### Operating Requirements

- Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accidental swallowing.
- Please use the accessories provided or authorized by the manufacturer only.
- The power supply of the device shall meet the requirements of the input voltage of the device. Please use the provided surge protection power socket only.
- Before plugging or unplugging any cable, make sure that your hands are completely dry.
- Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbowl, kitchen sink, wet basement or near a swimming pool.
- During a thunderstorm, stop using the device and disconnect it from the power supply. Unplug the power plug and the Asymmetric Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike.
- If the device is left unused for a rather long time, disconnect it from the power supply and unplug the power plug.
- When there is smoke emitted from the device, or some abnormal noise or smell, disconnect the device from the power supply, and unplug the power plug immediately.
- Contact the specified maintenance center for repair.
- Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- Before connecting a cable, connect the grounding cable of the device first. Do not disconnect the grounding cable until you disconnect all other cables.

#### Cleaning Requirements

- Before cleaning the device, disconnect it from the power supply.
- Use a piece of soft, dry and anti-static cloth to clean the device.
- Keep the power plug clean and dry.

### Troubleshooting

The unit cannot supply power to device other than Yealink device.

There is a bad connection with the plug.

1. Clean the plug with a dry cloth.

2. Connect it to another wall outlet.

The usage environment is out of operating temperature range.

1. Use in the operating temperature range.

The cable between the unit and the Yealink device is connected incorrectly.

1. Connect the cable correctly.

You cannot connect the cable properly.

1. You may have connected a wrong Yealink device.

2. Use the correct power supply.

Some dust, etc., may be in the port.

1. Clean the port.

Contact your dealer or authorized service facility for any further questions.

### FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### IC Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(1) this device may not cause interference; and

(2) this device must accept any interference, including interference that may cause undesired operation of the device. CAN ICES-3(B)

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage;

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.NMB-3(B)

### Contact Information

YEALINK NETWORK TECHNOLOGY CO.,LTD.

309, 3rd Floor, No.16, Yun Ding North Road, Huli District, Xiamen City, Fujian, P.R. C

YEALINK (EUROPE) NETWORK TECHNOLOGY B.V.

Strawinskylaan 3127, Atrium Building, 8th floor, 1077ZX Amsterdam, The Netherlands

YEALINK (USA) NETWORK TECHNOLOGY CO., LTD.

999 Peachtree Street Suite 2300, Fulton, Atlanta, GA, 30309, USA


Made in China

### About Yealink

Yealink is a global leading provider of enterprise communication and collaboration solutions, offering video conferencing service to worldwide enterprises. Focusing on research and development, Yealink also insists on innovation and creation. With the outstanding technical patents of cloud computing, audio, video and image processing technology, Yealink has built up a panoramic collaboration solution of audio and video conferencing by merging its cloud services with a series of endpoints products. As one of the best providers in more than 140 countries and regions including the US, the UK and Australia, Yealink ranks No.1 in the global market share of SIP phones shipments.

### Technical Support

Visit Yealink WIKI (<http://support.yealink.com/>) for the latest firmware, guides, FAQ, Product documents, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (<https://ticket.yealink.com>) to submit all your technical issues.



Camera - Hub- EN+ CN



YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.  
Web: [www.yealink.com](http://www.yealink.com)  
Copyright©2020 YEALINK(XIAMEN) NETWORK  
TECHNOLOGY CO.,LTD.All rights reserved.