



# PIXI IS A REUSABLE MULTI-PURPOSE TIE TO BUNDLE OR SECURE ANYTHING UNDER THE SUN.



# NEVER GO IN SEARCH OF SCISSORS TO CUT ANOTHER ZIP TIE AGAIN.

Pixi is an adjustable and reusable tie that can be used on every project imaginable. The elastomeric bungee at the end of Pixi keeps stuff tight and secure.

To use Pixi, simply loop the bungee end around the object you want to secure, bring the tail through the loop – just under the button fastner – and pull back to trap the bungee slack in the channel that runs the length of the button. To release, pull the slack to thin the bungee and free it from the locking channel.



# **SMALL PIXI**

Designed to tie up cables, small accessories, business cards and more.



## **MEDIUM PIXI**

Made to organize household electronics, bread or chip bags, stereo equipment, etc.



# LARGE PIXI

Perfect for camping gear, winding up a yoga mat, wrapping paper rolls and beyond.

<b>4</b> x	
<b>4</b> x	

Small, Medium and Large.

#### Small 8 Pack

**PIXI COMES IN THREE SIZES** 

Grey: 12 cm / 4.7 in Black: 20 cm / 7.8 in



3x 🚍


3x 🚍

### Small 8 Pack

Orange: 12 cm / 4.7 in Blue: 20 cm / 7.8 in

#### Medium 6 Pack

Green: 32 cm / 12.5 in Black: 44 cm / 17.3 in



#### Large 2 Pack

Red: 56 cm / 22 in Black: 84 cm / 33 in

#### **SPECIFICATIONS**

Package Contents: Varies.

#### SKUs

Small Grey/Black: PX-SM-01Small Orange/Blue: PX-SM-02Medium Green/Black: PX-MD-01Large Red/Black: PX-LG-01

#### **UPC Codes**

Small: 8 886466 091217Small: 8 886466 091224Medium: 8 886466 091231Large: 8 886466 091248

### **blueLounge**® Pte, Ltd

8 Wilkie Road #03-01 Wilkie Edge Singapore 228095 **T.** +65 649 15247

www.bluelounge.com