



x-Five Wireless

Getting started, safety and warranty


Product and controls overview

EN Product and controls overview

1. Audio buttons
2. Play/Pause
3. Microphone
4. LED
5. On/Off
6. Audio cable jack
7. Charging LED
8. USB jack

RU Руководство пользователя

1. Кнопки управления звуком
2. Кнопки проигрывания
3. Микрофон
4. LED
5. Кнопка включения
6. Аудио разъем
7. LED-индикатор уровня заряда
8. Разъем USB



Important safety instructions

1. Read, follow and keep these instructions.
2. For the best possible experience, always use the product as described by the manufacturer.
3. Always handle your headphones with care and protect them from external damage.
4. Clean your headphones using a soft dry cloth. Never use water, cleaning detergent, leather polish or other substances as they may damage your headphones permanently.
5. Avoid exposure to extreme conditions such as very cold or hot temperatures, magnetic fields or damp environments.
6. Listening to music at high volume for prolonged periods of time can cause permanent damage to your hearing.
7. Contains small parts and are not suitable for children age three (3) and below.
8. The headphones contain magnetic material.
9. The headphones contain a Lithium battery. If misused or damaged it can become a hazard and is at risk of explosion.
10. Should a battery cell leak, do not allow the liquid to come in contact with skin or eyes.
11. The headphones must be switched off before boarding an aircraft.
12. The headphones must not be disposed of with regular household waste. Please dispose of in accordance with local regulations.
13. Do not use your headphones in the immediate proximity (10 cm) of a pacemaker.
14. Do not subject the product and included accessories to abnormal wear and tear.
15. Do not expose the headphones to temperatures below -20°C or above +45°C.
16. Do not charge the headphones in temperatures below 0°C or above +45°C.
17. Do not attempt to burn the headphones. The battery could explode causing injury and death.
18. Do not attempt to open, modify, disassemble, repair or in other way access the internal structure of the headphones. They are not user serviceable.
19. Do not use or store the headphones near to a vehicle airbag due to risk of injury.
20. Do not use headphones while driving, jogging or walking through traffic areas. Headphones effectively isolate external sound and noise, which means that when in use, you might not be able to hear your surroundings.
21. Do not drop, sit on or cause other unusual impact to the headphones.
22. Do not expose to fire, water or high voltage equipment.
23. Do not expose the product to rain or moisture.
24. Do not use the headphones near water, bathtubs, sinks, saunas, pools, other liquids or moist areas.

Statements

EU Declaration of conformity

Hereby Jays Group AB declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and all other EU directive requirements. The complete declaration of conformity can be found at www.jaysheadphones.com.

Caution

Risk of explosions if battery box is damaged or opened. Dispose of used battery according to your local waste disposal authority.

Model name: X5W01



Complies with
IMDA Standards
DA105282

Getting started

Power on/off and pairing

To power on, press and hold the on/off button for 2s, the LED will blink in blue three times. To pair, press and hold the on/off button for 5s, the LED will blink in blue and red. Go to Bluetooth® settings on your device and select "JAYS x-Five Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the on/off button for 2s, the LED will blink in red.

Reconnecting

Next time you power on, the headphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press and hold the on/off button for 5s from off state.

Using the audio cable

Connect the audio cable to the audio jack and your device. The LED will blink in red twice as Bluetooth® pairing with your device disconnects automatically.

Battery status and charging

When paired with iOS devices, the battery status of the headphones is shown in the upper right corner on the iOS device.

Charge by connecting the included USB cable to the USB jack and connect it to any certified USB power output. A full 100% charge will take around 2 - 3 hours (depending on temperature and charger).

Charging is indicated by a solid red light on the charging LED, and a full charge is indicated by a solid green light on the charging LED.

Troubleshooting

Problem pairing and connecting

- Make sure the headphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the headphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.



Manufacturer's limited warranty

Your original Jays Group AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays Group AB product by the original purchaser. Jays Group AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays Group AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, age-related battery capacity loss, accidents, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modifications or repairs performed by yourself or third party without Jays Group AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.

Предупреждение о безопасности

1. Прочтите, соблюдайте и сохраните данную инструкцию
2. Используйте продукт по назначению, указанному производителем
3. Берегите наушники и защищайте их от внешних повреждений
4. Избегайте воздействия экстремальных условий, низких или высоких температур, магнитных полей и влажной среды
5. Избегайте воздействия экстремальных условий, низких или высоких температур, магнитных полей и влажной среды
6. При постоянном использовании высокого уровня громкости слух адаптируется к такой силе звукового воздействия, что может привести к долговременному ухудшению слуха без какого-либо ощущения дискомфорта
7. Содержит мелкие детали, храните в недоступном для детей месте
8. Наушники содержат магнитный материал
9. Наушники содержат литиевую батарею, в случае неправильного использования или повреждения они могут быть подвержены риску взрыва
10. В случае протечки элемента батареи не допускайте контакта жидкости с кожей или глазами
11. Наушники должны быть выключены перед посадкой в самолет
12. Не выбрасывайте вместе с обычными бытовыми отходами
13. Не используйте наушники в непосредственной близости (10 см) от кардиостимулятора
14. Не подвешивайте кабели или разъемы аномальному износу
15. Не подвергайте наушники воздействию температур ниже -20 или выше +45 °C
16. Не заряжайте наушники при температуре ниже 0 или выше +45 °C
17. Не пытайтесь сжать наушники. Аккумулятор может взорваться, что может привести к травме или смерти.
18. Не пытайтесь вскрыть, модифицировать, разобрать, отремонтировать или иным способом получить доступ к внутренней структуре наушников. Они не обслуживаются пользователем
19. Не используйте и не храните наушники рядом с подушкой безопасности автомобиля из-за опасности получения травм
20. Не используйте наушники во время вождения, бега трусцой или ходьбы по дорогам. Наушники эффективно изолируют внешний звук и шум, что означает, что при их использовании вы не сможете слышать окружающие звуки
21. Не роняйте, не садитесь и не наносите другие удары по наушникам
22. Не подвергайте воздействию огня, воды или высоковольтного оборудования
23. Не подвергайте воздействию дождя или влаги
24. Не используйте наушники рядом с водой, ваннами, раковинами, саунами, бассейнами, другими жидкостями или влажными зонами.

Сертификация

Декларация соответствия

Настоящим Jays AB заявляет, что этот продукт соответствует основным требованиям и другим соответствующим положениям Директивы 2014/53/ЕС и другим директивам ЕС. Полную декларацию соответствия можно найти на www.jaysheadphones.com

Осторожно

ОПАСНОСТЬ ВЗРЫВА ПРИ ЗАМЕНЕ БАТАРЕИ НЕПРАВИЛЬНОГО ТИПА. УТИЛИЗИРУЙТЕ ИСПОЛЬЗОВАННЫЕ БАТАРЕИ В СООТВЕТСТВИИ С ИНСТРУКЦИЯМИ.

НЕ ИМЕЕТ ВСТРОЕННОГО ЗАПОМИНАЮЩЕГО УСТРОЙСТВА.

Начало использования

Включение/выключение

Для включения зажмите кнопку до тех пор, пока светодиод не моргнет голубым 3 раза. Для создания пары с вашим устройством зажмите кнопку включения, пока светодиод не начнет мигать голубым и красным. Перейдите к настройкам Bluetooth® на вашем устройстве и выберите «JAYS x-five Wireless». Светодиод начнет быстро мигать, а затем выключится при успешном соединении.

Повторное и дополнительное подключение

В следующий раз, когда вы включите литиевые наушники, они попытаются снова подключиться к последнему использованному устройству. Если устройство не найдено или вы вручную отключили свое устройство, режим подключения будет автоматически перезапущен.

Использование аудио разъема

Вставьте кабель в аудио разъем, светодиод загорится красным, т.к. соединение Bluetooth® с вашим устройством будет отключено автоматически.

Состояние батареи и зарядка

При подключении к iOS устройству, уровень заряда батареи будет отображаться на экране устройства в правом углу.

Осуществляйте заряд батареи путем подключения USB кабеля в USB разъем, 100% уровень заряда будет достигнут за 2-3 часа.

Состояния заряда отображаются светодиодом, при полной зарядке его цвет сменится с красного на зеленый.

Устранение проблем

Проблемы с подключением

- Убедитесь, что наушники не подключены к другому устройству
- Выключите и включите Bluetooth® на вашем устройстве
- Переместите наушники ближе к устройству или измените их положение

Проблемы с передачей звука

Измените положение тела, проверьте, что никакие другие предметы не препятствуют прохождению сигнала между наушниками и вашим устройством

Гарантия производителя

Информация об утилизации

Продукт соответствует директиве 2012/19/ЕС, не подлежит утилизации с обычными бытовыми отходами. Утилизацию изделия, аккумуляторов и зарядного устройства производителе в соответствии с местными стандартами и законодательно-нормативными актами.



Ограниченная гарантия производителя

На ваш оригинальный продукт Jays Group AB распространяется гарантия в течение двенадцати (12) месяцев с момента приобретения покупателем совершенно нового, неисправного изделия Jays Group AB. Jays Group AB гарантирует, что изделие не имеет дефектов в материалах, дизайне и изготовлении, на момент продажи покупателю. Если вы не можете предоставить чека при подаче гарантийного требования, вам придется оплатить все произведенные ремонтные работы. В чеке должны быть указаны дата покупки, название продукта и данные уполномоченных реселлеров.

Гарантийный период не может быть продлен или возобновлен в связи с последующей перепродажей или заменой продукта.

Что не покрывает ограниченная гарантия?

- Неисправности, вызванные износом, аварией, падением, механическим повреждением, влагой, химическими продуктами, ударом или форс-мажорными обстоятельствами
- Модификации или самостоятельный ремонт/ремонт третьей стороной без одобрения Jays Group AB

Как получить гарантийное обслуживание

Если вы хотите подать Гарантийное заявление в течение Гарантийного срока, обратитесь к реселлеру вашего продукта за дальнейшей помощью. Вам будет необходимо предоставить чек в подтверждение своей покупки. Любые дефектные детали, на которые распространяется Ограниченная гарантия, будут отремонтированы или заменены бесплатно. Для получения ответов на часто задаваемые вопросы посетите сайт www.jaysheadphones.com

Jays Group AB
Nellickevägen 22, 412 63 Gothenburg, Sweden

www.jaysheadphones.com



jaysheadphones



facebook.com/jays