


# Desktop PC G10DK User Guide





E17987 First Edition February 2021

#### Copyright © 2021 ASUSTeK Computer Inc. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTEK Computer Inc. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification of alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

# Contents

Notices	4
Safety information	9
Conventions used in this guide	10
Where to find more information	10
Package contents	11

# Chapter 1 Getting started

Welcome!	13
Getting to know your computer	13
Setting up your computer	17
Turning your computer ON	19

# Chapter 2 Connecting devices to your computer

Connecting a USB storage device	21
Connecting microphone and speakers	22
Connecting multiple external displays	25
Connecting an HDTV	26

# Chapter 3 Using your computer

Proper posture when using your Desktop PC2	7
--	---

# Chapter 4 Connecting to the Internet

Wired connection	29
Wi-Fi connection (on selected models only)	33

# Chapter 5 Troubleshooting

Troubleshooting
-----------------

# Appendix

# Using Windows<sup>®</sup> 10

ASUS contact information	
Keyboard shortcuts	.48
Using the Windows <sup>®</sup> 10 UI	.44
Starting for the first time	.43

ASUS contact information
--------------------------

# Notices

# **ASUS Recycling/Takeback Services**

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components, as well as the packaging materials. Please go to <a href="http://csr.asus.com/english/Takeback.htm">http://csr.asus.com/english/Takeback.htm</a> for the detailed recycling information in different regions.

# REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <u>http://csr.asus.com/english/REACH.htm</u>

# **Federal Communications Commission Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference; and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

#### Lithium Battery Warning

**CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

#### Avertissement relatif aux batteries Lithium

**ATTENTION !** Danger d'explosion si la batterie n'est pas correctement remplacée. Remplacer uniquement avec une batterie de type semblable ou équivalent, recommandée par le fabricant. Jeter les batteries usagées conformément aux instructions du fabricant.

# Compliance Statement of Innovation, Science and Economic Development Canada (ISED)

This device complies with Innovation, Science, and Economic Development Canada licence exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device:

Operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

CAN ICES-003(B)/NMB-003(B)

# Déclaration de conformité de Innovation, Sciences et Développement économique Canada (ISED)

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canadaapplicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

La bande 5150 – 5250 MHz est réservée uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

CAN ICES-003(B)/NMB-003(B)

# **IC: Canadian Compliance Statement**

Complies with the Canadian ICES-003 Class B specifications. This device complies with RSS 210 of Industry Canada. This Class B device meets all the requirements of the Canadian interferencecausing equipment regulations.

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

## Déclaration de conformité d'Industrie Canada

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Le présent appareil est conforme aux normes CNR d'Industrie Canada applicables aux appareils radio exempts de licence. Son utilisation est sujette aux deux conditions suivantes : (1) cet appareil ne doit pas créer d'interférences et (2) cet appareil doit tolérer tout type d'interférences, y compris celles susceptibles de provoquer un fonctionnement non souhaité de l'appareil.

# **Canadian Department of Communications Statement**

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

# Déclaration du Département Canadien des Communications

Cet appareil numérique ne dépasse pas les limites de classe B en terme d'émissions de nuisances sonores, par radio, par des appareils numériques, et ce conformément aux régulations d'interférence par radio établies par le département canadien des communications. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

# VCCI: Japan Compliance Statement

## VCCI Class B Statement

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目 的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、 受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

This is a Class B product based on the standard of the VCCI Council. If this is used near a radio or television receiver, it may cause radio interference. Install and use equipment according to the instruction manual.

# Equipment registered based on the confirmation measurement at the user installation site.

この装置は、現在設置されている場所で妨害波の測定がされた情報技術装置であり、

VCCI協会の基準に適合しています。

従って、現在設置されている場所以外で使用する場合は、再び妨害波を測定し、VC

CIに届け出をしなければなりません。

This is a product for which interference was measured at the present installation site and confirmed to comply with the standard of Voluntary Control Council for Interference by Information Technology Equipment (VCCI). Before using the equipment at any location other than the present installation site, the member shall measure interference for confirmation and register the result to VCCI.

## India E-Waste (Management) Rules 2016

This product complies with the "India E-Waste (Management) Rules, 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls (PBBs) and polybrominated diphenyl ethers (PBDEs) in concentrations exceeding 0.1% by weight in homogenous materials and 0.01% by weight in homogenous materials for cadmium, except for the exemptions listed in Schedule II of the Rule.

## **KC: Korea Warning Statement**

B급 기기 (가정용 방송통신기자재) 이 기기는 가정용(B급) 전자과적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며,모든 지역에서 사용할 수 있습니다.

\*당해 무선설비는 전파훈신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습 니다.

# **RF Equipment Notices**

#### **CE: European Community Compliance Statement**

The equipment complies with the RF Exposure Requirement 1999/519/EC, Council Recommendation of 12 July 1999 on the limitation of exposure of the general public to electromagnetic fields (0–300 GHz).

#### **Wireless Radio Use**

This device is restricted to indoor use when operating in the 5.15 to 5.25 GHz frequency band. For the standard EN 300 440, the device operating in 802.11a/n/ac mode is considered as a receiver category 2.

#### **Exposure to Radio Frequency Energy**

The radiated output power of the Wi-Fi technology is below the FCC radio frequency exposure limits. Nevertheless, it is advised to use the wireless equipment in such a manner that the potential for human contact during normal operation is minimized.

#### FCC Bluetooth Wireless Compliance

The antenna used with this transmitter must not be colocated or operated in conjunction with any other antenna or transmitter subject to the conditions of the FCC Grant.

#### **Bluetooth Industry Canada Statement**

This Class B device meets all requirements of the Canadian interference-causing equipment regulations.

Cet appareil numérique de la Class B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

#### **BSMI: Taiwan Wireless Statement**

低功率射頻器材技術規範

「取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加 大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通 信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。前述合法通信,指 依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用 電波輻射性電機設備之干擾。」

\* 應避免影響附近雷達系統之操作。



工作頻率 5.250 ~ 5.350GHz 該頻段限於室內使用。

#### Japan RF Equipment Statement

この製品は、周波数帯域5.15~5.35GHzで動作しているときは、屋内においてのみ使用可能です。

#### **KC (RF Equipment)**

대한민국 규정 및 준수 방통위고시에 따른 고지사항 해당 무선설비는 운용 중 전파혼신 가능성이 있음, 이 기기는 인명안전과 관련된 서비스에 사용할 수 없습니다.

# Simplified EU Declaration of Conformity

ASUSTek Computer Inc. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. Full text of EU declaration of conformity is available at <u>https://www.asus.com/support/</u>.

The Wi-Fi operating in the band 5150-5350MHz shall be restricted to indoor use for countries listed in the table below:

AT	BE	BG	CZ	DK	EE	FR
DE	IS	IE	IT	EL	ES	CY
LV	LI	LT	LU	HU	MT	NL
NO	PL	PT	RO	SI	SK	TR
FI	SE	CH	UK	HR		



# **Optical Drive Safety Information**

#### **Laser Safety Information**

CD-ROM Drive Safety Warning

# **CLASS 1 LASER PRODUCT**

**WARNING!** To prevent exposure to the optical drive's laser, do not attempt to disassemble or repair the optical drive by yourself. For your safety, contact a professional technician for assistance.

#### Service warning label



WARNING! INVISIBLE LASER RADIATION WHEN OPEN. DO NOT STARE INTO BEAM OR VIEW DIRECTLY WITH OPTICAL INSTRUMENTS.

## **CDRH Regulations**

The Center for Devices and Radiological Health (CDRH) of the U.S. Food and Drug Administration implemented regulations for laser products on August 2, 1976. These regulations apply to laser products manufactured from August 1, 1976. Compliance is mandatory for products marketed in the United States.



**WARNING!** Use of controls or adjustments or performance of procedures other than those specified herein or in the laser product installation guide may result in hazardous radiation exposure.

# **Coating notice**



**IMPORTANT!** To provide electrical insulation and maintain electrical safety, a coating is applied to insulate the device except on the areas where the I/O ports are located.

# **Safety information**



Disconnect the AC power and peripherals before cleaning. Wipe the Desktop PC using a clean cellulose sponge or chamois cloth dampened with solution of nonabrasive detergent and a few drops of warm water then remove any extra moisture with a dry cloth.

- DO NOT place on uneven or unstable work surfaces. Seek servicing if the casing has been damaged.
- DO NOT expose to dirty or dusty environments. DO NOT operate during a gas leak.
- DO NOT place or drop objects on top and do not shove any foreign objects into the Desktop PC.
- DO NOT expose to strong magnetic or electrical fields.
- DO NOT expose to or use near liquids, rain, or moisture. DO NOT use the modem during electrical storms.
- Battery safety warning: DO NOT throw the battery in fire. DO NOT short circuit the contacts.
   DO NOT disassemble the battery.
- Use this product in environments with ambient temperatures between 0°C (32°F) and 35°C (95°F).
- **DO NOT** cover the vents on the Desktop PC to prevent the system from getting overheated.
- DO NOT use damaged power cords, accessories, or other peripherals.
- To prevent electrical shock hazard, disconnect the power cable from the electrical outlet before relocating the system.
- Seek professional assistance before using an adapter or extension cord. These devices could interrupt the grounding circuit.
- Ensure that your power supply is set to the correct voltage in your area. If you are not sure
  about the voltage of the electrical outlet you are using, contact your local power company.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.



Hazardous moving parts. Desktop should be completely shutdown before servicing product. Replacing fan components should only be attempted by qualified service personnel.

#### Hazardous Moving Parts Warning

WARNING: Keep fingers and other body parts away from any moving parts.

# Conventions used in this guide

To ensure that you perform certain tasks properly, take note of the following symbols used throughout this manual.



**DANGER/WARNING:** Information to prevent injury to yourself when trying to complete a task.



**CAUTION:** Information to prevent damage to the components when trying to complete a task.



**IMPORTANT:** Instructions that you MUST follow to complete a task.



**NOTE:** Tips and additional information to help you complete a task.

# Where to find more information

Refer to the following sources for additional information and for product and software updates.

#### **ASUS** websites

The ASUS website provides updated information on ASUS hardware and software products. Refer to the ASUS website <u>www.asus.com</u>.

#### **ASUS Local Technical Support**

Visit ASUS website at <u>https://www.asus.com/support/contact</u> for the contact information of local Technical Support Engineer.

# Package contents

Desktop PC G10DK	Keyboard x1	Mouse x1
	Installation Guide	Warrantu
Power cord x1	Installation Guide x1	Warranty Card x1



• If any of the above items is damaged or missing, contact your retailer.

The illustrated items above are for reference only. Actual product specifications may vary with different models.




# Welcome!

Thank you for purchasing the ASUS Desktop PC!

The ASUS Desktop PC provides cutting-edge performance, uncompromised reliability, and usercentric utilities. All these values are encapsulated in a stunningly futuristic and stylish system casing.



Read the ASUS Warranty Card before setting up your ASUS Desktop PC.

# Getting to know your computer



Illustrations are for reference only. The ports, their locations and the chassis color vary with different models.

Front Тор 1 2 - IA 3 Power button. Press this button to turn on your computer. 1 2

Headset port. This port connects to a headset, headphone, microphone, or speaker.




**ENGLISH** 

USB 3.2 Gen 1 ports. These ports connect to USB 3.2 Gen 1 devices such as a mouse, printer, scanner, camera, PDA, and others.



USB 3.2 Gen 1 devices can only be used for data storage.

Rear



PS/2 keyboard/mouse combo port. This port is for a PS/2 keyboard/mouse.



1

**USB 3.2 Gen 1 ports.** These 9-pin Universal Serial Bus (USB) ports connect to USB 3.2 Gen 1 devices.



**DVI-D port.** This port is for any DVI-D compatible device.

- DVI-D can not be converted to output from RGB Signal to CRT and is not compatible with DVI-I.
- The on-board DVI-D and VGA ports only work while using a CPU with integrated graphics.

	DVI-D	VGA
Ryzen CPU - Vermeer	Not support	Not support
Ryzen CPU - Matisse	Not support	Not support
Ryzen APU - Picasso	Support	Support



5

VGA port. This port is for VGA-compatible devices such as a VGA monitor.

HDMI<sup>™</sup> port. This port is for a High-Definition Multimedia Interface (HDMI<sup>™</sup>) connector, and is HDCP compliant allowing playback of HD DVD, Blu-ray, and other protected content.



**USB 3.2 Gen 2 ports.** These 9-pin Universal Serial Bus (USB) ports are for USB 3.2 Gen 2 devices.

Ø

We strongly recommend that you connect USB 3.2 Gen 2 devices to USB 3.2 Gen 2 ports for faster and better performance for your USB 3.2 Gen 2 devices.



Microphone port (pink). This port connects to a microphone.



**Line Out port (lime).** This port connects to a headphone or speaker. In a 4, 5.1, or 7.1-channel configuration, the function of this port becomes Front Speaker Out.



Line In port (light blue). This port connects to a tape, CD, DVD player, or other audio sources.

Refer to the audio configuration table below for the function of the audio ports in the 2, 4, 5.1, or 7.1-channel configuration.

#### Audio 2, 4, 5.1, or 7.1-channel configuration

Port	Headset 2-channel	4-channel	5.1-channel	7.1-channel
Light Blue (Rear panel)	Line In	Rear Speaker Out	Rear Speaker Out	Rear Speaker Out
Lime (Rear panel)	Line Out	Front Speaker Out	Front Speaker Out	Front Speaker Out
Pink (Rear panel)	Mic In	Mic In	Bass/Center	Bass/Center
Lime (Front panel)	-	-	-	Side Speaker Out



**Power connector.** Plug the power cord to this connector.

RATING: • 115Vac/230Vac, 9A/4.5A, 50Hz/60Hz (WW, TW)

• 220Vac, 4.5A, 50Hz (China)



Air vents. These vents allow air ventilation.

DO NOT block the air vents on the chassis. Always provide proper ventilation for your computer.



LAN (RJ-45) port. This port allows Gigabit connection to a Local Area Network (LAN) through a network hub.

## LAN port LED indications

Activity/Link LED		Speed LED	
Status	Description	Status	Description
OFF	No link	OFF	10Mbps connection
ORANGE	Linked	ORANGE	100Mbps connection
BLINKING	Data activity	GREEN	1Gbps connection

#### ACT/LINK LED SPEED LED





**ASUS Graphics Cards (on selected models only).** The display output ports on these optional ASUS Graphics Cards may vary with different models.



**Expansion slot brackets.** Remove the expansion slot bracket when installing an expansion card.

# Setting up your computer

This section guides you through connecting the main hardware devices, such as the external monitor, keyboard, mouse, and power cord to your computer.

# Connecting an external monitor

## Using the ASUS Graphics Card (on selected models only)


Connect your monitor to the display output port on the discrete ASUS Graphics Card.

#### To connect an external monitor using the ASUS Graphics Card:

- 1. Connect a monitor to a display output port on the ASUS Graphics Card.
- 2. Plug the monitor to a power source.


S

The display output ports on the ASUS Graphics Card may vary with different models.




# Connecting a USB keyboard and a USB mouse

Connect a USB keyboard and a USB mouse to the USB ports on the rear panel of your computer.



# Connecting the power cord

Connect one end of the power cord to the power connector on the rear panel of your computer and the other end to a power source.




ENGLISH

# Turning your computer ON

This section describes how to turn on your computer after setting up your computer.

## To turn your computer ON:

- 1. Turn your monitor ON.
- 2. Press the power button on your computer.



3. Wait until the operating system loads automatically.

Т	
S	
G	
Ž	
ш	


# **Chapter 2**

# Connecting devices to your computer


# Connecting a USB storage device

This desktop PC provides USB 3.2 Gen 1, and USB 3.2 Gen 2 ports on the front and rear panels. The USB ports allow you to connect USB devices such as storage devices.


#### To connect a USB storage device:

Insert the USB storage device to your computer.

# **Front panel**




**Rear panel** 




# **Connecting microphone and speakers**

This desktop PC comes with microphone ports and speaker ports on both the front and rear panels. The audio I/O ports located on the rear panel allow you to connect 2-channel, 4-channel, 5.1-channel, and 7.1-channel speakers.

# **Connecting headset**




## **Connecting 2-channel Speakers**




# ENGLISH


# **Connecting 4-channel Speakers**



# **Connecting 5.1-channel Speakers**



# **Connecting 7.1-channel Speakers**



# **Connecting multiple external displays**


Your desktop PC may come with VGA, HDMI<sup>™</sup>, or DVI ports and allows you to connect multiple external displays.

# Setting up multiple displays

When using multiple monitors, you are allowed to set display modes. You can use the additional monitor as a duplicate of your main display, or as an extension to enlarge your Windows desktop.

#### To set up multiple displays:

- 1. Turn off your computer.
- 2. Connect the two monitors to your computer and connect the power cords to the monitors. Refer to **Setting up your computer** section in Chapter 1 for details on how to connect a monitor to your computer.



- 3. Turn on your computer.
- 4. From the Start menu, click **Settings** > **System** > **Display**.
- 5. Configure the settings for your displays.




For some graphic cards, only the monitor that is set to be the primary display has display during POST. The dual display function works only under Windows.

# **Connecting an HDTV**

Connect a High Definition TV (HDTV) to the HDMI<sup>™</sup> port of your computer.



- You need an HDMI<sup>™</sup> cable to connect the HDTV and the computer. The HDMI<sup>™</sup> cable is purchased separately.
- To get the best display performance, ensure that your HDMI<sup>™</sup> cable is less than 15 meters.



# Chapter 3 Using your computer

# Proper posture when using your Desktop PC

When using your Desktop PC, maintaining the proper posture is necessary to prevent strain to your wrists, hands, and other joints or muscles. This section provides you with tips on avoiding physical discomfort and possible injury while using and fully enjoying your Desktop PC.



#### To maintain the proper posture:

- Position your computer chair to make sure that your elbows are at or slightly above the keyboard to get a comfortable typing position.
- Adjust the height of your chair to make sure that your knees are slightly higher than your hips to relax the backs of your thighs. If necessary, use a footrest to raise the level of your knees.
- Adjust the back of your chair so that the base of your spine is firmly supported and angled slightly backward.
- Sit upright with your knees, elbows and hips at an approximately 90° angle when you are at the PC.
- Place the monitor directly in front of you, and turn the top of the monitor screen even with your eye level so that your eyes look slightly downward.
- Keep the mouse close to the keyboard, and if necessary, use a wrist rest for support to reduce the pressure on your wrists while typing.
- Use your Desktop PC in a comfortably-lit area, and keep it away from sources of glare such as windows and straight sunlight.
- Take regular mini-breaks from using your Desktop PC.

Т	
S	
G	
Ž	
ш	


# Chapter 4 Connecting to the Internet

# Wired connection

Use an RJ-45 cable to connect your computer to a DSL/cable modem or a local area network (LAN).

# Connecting via a DSL/cable modem


# To connect via a DSL/cable modem:

1. Set up your DSL/cable modem.



Refer to the documentation that came with your DSL/cable modem.

2. Connect one end of an RJ-45 cable to the LAN (RJ-45) port on the rear panel of your computer and the other end to a DSL/cable modem.



- 3. Turn on the DSL/cable modem and your computer.
- 4. Configure the necessary Internet connection settings.




- Contact your network administrator for details or assistance in setting up your Internet connection.
- For more details, refer to the sections **Configuring a dynamic IP/PPPoE network connection** or **Configuring a static IP network connection**.

# Connecting via a local area network (LAN)

## To connect via a LAN:

1. Connect one end of an RJ-45 cable to the LAN (RJ-45) port on the rear panel of your computer and the other end to your LAN.



- 2. Turn on your computer.
- 3. Configure the necessary Internet connection settings.



- Contact your network administrator for details or assistance in setting up your Internet connection.
- For more details, refer to the sections **Configuring a dynamic IP/PPPoE network connection** or **Configuring a static IP network connection**.

#### Configuring a dynamic IP/PPPoE network connection

#### To configure a dynamic IP/PPPoE network connection:

- 1. Launch **Network and Sharing Center** in either of these two ways:
  - a) From the taskbar, right-click 🔽 , then click **Open Network and Sharing Center**.
  - b) From the Start menu, click Settings > Network & Internet > Ethernet > Network and Sharing Center.
- 2. From the Open Network and Sharing Center screen, click **Change Adapter settings**.
- 3. Right-click on your LAN and select **Properties**.
- 4. Click Internet Protocol Version 4(TCP/ IPv4) and click Properties.

5.	Click Obtain an IP address automatically
	and click <b>OK</b> .

Connect using:  Connect using:  Configure  This connection uses the following items:  Configure  Configure  This connection uses the following items:  Configure  Confi	Connect using:  Connect using:  Reatek PCIe GBE Family Controller  This connection uses the following items:  Configure  This connection uses the following items:  Configure  Con	Ethernet Properties					
Reatek PCIe GBE Family Controller Configure This connection uses the following items: Install Configure Install Uninstall Properties Protocol Driver Install Uninstall Properties Protocol Version 4 (TCP/IPV6) Install Uninstall Properties Properties Protocol Driver Install Uninstall Properties Protocol Version 4 (TCP/IPV6) Use thick-tayer Topology Discovery Responder Install Uninstall Properties Properties Protocol Version 4 (TCP/IPV6) Use thick-tayer Topology Discovery Responder OK Cancel Control Tratecol/Internet Protocol The default wide area retwork protocol that provides communication across diverse interconnected networks. OK Cancel Control Tratecol/Internet Protocol Version 4 (TCP/IPV4) Properties Description Transmission Control Tratecol/Internet Protocol The default wide area retwork protocol that provides communication across diverse interconnected networks. OK Cancel OK Cancel Oktion an P address automatically Ouse the following IP address: IP address: Subhit DNS server address automatically Ouse the following DNS server addresses: Prefered DNS server: Atternate DNS server: Atternate DNS server: Atternate DNS server:	Reatek PCIe GBE Family Controller   Configure   This connection uses the following items:   Image: Standard S	letworking					
Reatek PCIe GBE Family Controller Configure This connection uses the following items: Install Configure Install Uninstall Properties Protocol Driver Install Uninstall Properties Protocol Version 4 (TCP/IPV6) Install Uninstall Properties Properties Protocol Driver Install Uninstall Properties Protocol Version 4 (TCP/IPV6) Use thick-tayer Topology Discovery Responder Install Uninstall Properties Properties Protocol Version 4 (TCP/IPV6) Use thick-tayer Topology Discovery Responder OK Cancel Control Tratecol/Internet Protocol The default wide area retwork protocol that provides communication across diverse interconnected networks. OK Cancel Control Tratecol/Internet Protocol Version 4 (TCP/IPV4) Properties Description Transmission Control Tratecol/Internet Protocol The default wide area retwork protocol that provides communication across diverse interconnected networks. OK Cancel OK Cancel Oktion an P address automatically Ouse the following IP address: IP address: Subhit DNS server address automatically Ouse the following DNS server addresses: Prefered DNS server: Atternate DNS server: Atternate DNS server: Atternate DNS server:	Reatek PCIe GBE Family Controller   Configure   This connection uses the following items:   Image: Standard S	Constanting to the second seco					
Configure This connection uses the following items:  Configure This connection uses the following items:  Configure Configure.	Configure This connection uses the following items:  Configure This connection uses the following items:  Configure Configure.		Sector				
This connection uses the following items:	This connection uses the following items:		Controller				
Construction Cons	Ocs Packet Scheduler     Internet Protocol Version 4 (TCP/IPv4)     Internet Protocol Driver     Internet Protocol Driver     Internet Protocol Version 6 (TCP/IPv6)     Internet Protocol Version 6 (TCP/IPv6)     Internet Protocol Version 6 (TCP/IPv6)     OK     Internet Protocol Version 6 (TCP/IPv6)     OK     Cencel     OK     Cencel     Internet Protocol Version     OK     Cencel     Internet Protocol Version     OK     Cencel     OK     Cencel     Internet Protocol Version     Internet Protocol Version     OK     Cencel     OK     Cencel     Internet Protocol Version     Internet Protocol     Internet Protocol     Internet Protocol     Internet Protocol     Internet Protocol     Internet Protocol     Internet     Inter				Con	figure	
Hernet Protocol Version 4 (TCP/IPv4)     Huk-Layer Topology Discovery Mapper I/O Driver     Microsoft HLUP Protocol Driver     Microsoft HLUP Protocol Driver     Install     Uninstall     Properties     Install     Uninstall     Properties     Install     Uninstall     Properties     OK     Cancel     OK     Cancel     OK     Cancel     Install     OK     Cancel     OK     Cancel     OK     Cancel     OK     Cancel     Description     Transmission Control Protocol Integration     across diverse interconnected networks.     OK     Cancel     OK			g items:				
	A Unix-Layer Topology Discovery Mapper I/O Driver      Morosoft Network Adapter Multiplexor Protocol      Morosoft LDP Protocol Driver      Morosoft Driver Driver Driver Driver Driver Driver Driver      Morosoft Driver Dri			_			^
A Increase the Nursek Adapter Multiplexor Protocol     A Internet Protocol Driver     A Internet Protocol Version 6 (TCP/IPV6)     A Internet Protocol Version 6 (TCP/IPV6)     A Internet Protocol Version 6 (TCP/IPV6)     A Internet Protocol Version 4 (TCP/IPV4)     OK Cancel     OK Cancel     Alternate Configuration     OK Otain an IP address automatically     Obtain CNS server addresses:     Prefered DMS server addresses:     Prefered DMS server:     Atternate DMS server:     Atternate DMS server:     Atternate DMS server:	Alkernate Configuration     Alkernate Configuration				iO Dei	(or	
Microsoft LLDP Protocol Driver Install Uninstall Properties Install Uninstall Properties Install Uninstall Properties Description Transmission Control Protocol/Internet Protocol. The default wide area network protocol (Internet Protocol. The default wide area network protocol with a provides communication across diverse interconnected networks.           OK         Cancel           OK         Cancel           Uninstall         OK           OB         OK           Cancel         OK           Cancel         OK           Obtain an IP address automatically         If your network administrator for the appropriate IP address:           IP address:         .           Subnet mask:         .           Obtain DNS server address automatically         Ouse the following DNS server:           Obtain DNS server:         .           Atternate DNS server:         .	Microsoft LLDP Protocol Driver     Microsoft LLDP Protocol Driver     Microsoft LLDP Protocol Driver     Microsoft LLDP Protocol Driver     Microsoft LLDP Protocol/View Responder     Microsoft LLDP Properties     Install Uninstall Properties     Microsoft Control Protocol/Viewent Protocol. The default     wide area network protocol that provides communication     across diverse interconnected networks.     OK Cancel     Microsoft UP/IP/4) Properties     meral Alternate Configuration     for darge pastings assigned automatically if your network supports     inscapability. Otherwise, you need to ask your network administrator     of the appropriate IP settings.     Subnet mask:         Location Protocol/Microsoft         Justing assigned automatically         Use the following DNS server addresses:     Preferred DNS server:         Atternate DNS server:         Advanced						
Install Uninstall Properties   Description   Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.   OK   Cancel   OK Cancel   Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.   OK   Cancel   Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.   OK   Cancel   Contain an UP address automatically   Obtain an UP address automatically   Out be the following IP address:   Subnet mask:   Default gateway:   Obtain DNS server address automatically  Outs the following DNS server addresses: Prefered DNS server: Atternate DNS server: Atternate DNS server: Atternate DNS server: Atternate DNS server:							
Install Uninstall Properties  Install Uninstall Properties Description Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.  OK Cancel  remet Protocol Version 4 (TCP/IPv4) Properties eneral Alternate Configuration Tou can get IP settings assigned automatically if your network administrator for the appropriate IP settings.  Obtain an IP address automatically Ouse the following IP address: Subnet mask: Default Qateway:  Ouse the following DNS server addresses: Profered DNS server: Atternate DNS server:	Install Uninstall Properties     Description     Transmission Control Protocol/Internet Protocol. The default     wide area network protocol that provides communication     across diverse interconnected networks.     OK Cancel     OK Cancel     Install Alternate Configuration     for the appropriate IP settings     obtain an IP address submatically     Ouse the following IP address:     performed to sak your network administrator     obtain DNS server addresses:     Preferred DNS server:						
Install       Uninstall       Properties         Description       Transmission Control Protocol/Internet Protocol The default wide area refuxed protocol that provides communication across diverse interconnected networks.       OK       Cancel         OK       Cancel       OK       Cancel         errent Protocol Version 4 (TCP/IPv4) Properties       eneral       Atternate Configuration         You can get IP settings assigned automatically if your network administrator for the appropriate IP settings.       •       •         © Obtain an IP address:       IP       •       •       •         IP address:	Install     Uninstall     Properties       Description     Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.       OK     Cancel       OK     Cancel		covery Re	sponde	er		~
Description     Transmission Control Protocol/Internet Protocol. The default     wide area network protocol that provides communication     across diverse interconnected networks.     OK Cancel  ernet Protocol Version 4 (TCP/IPv4) Properties eneral     Alternate Configuration  You can get IP settings     assigned automatically if your network supports     the capability. Otherwise, you need to ask your network administrator     for the appropriate IP settings      Obtain an IP address automatically     Use the following IP address:     IP address:     John DNS server addresses:     Perfored DNS server:     Atternate DNS server:     Atternate DNS server:     Atternate DNS server:	Description     Transmission Control Protocol/Internet Protocol. The default     wide area network protocol that provides communication     across diverse interconnected networks.     OK Cancel  ernet Protocol Version 4 (TCP/IPvd) Properties  ernet Protocol Version 1 (TCP/IPvd) Properties  ernet Protocol Version 2 (TCP/IPvd) Properties  ernet Protocol Versi (TCP/IPvd) Properties  ernet Protocol Version 2 (	×					
Transmission Control Protocol/Internet Protocol The default wide area network protocol that provides communication across diverse interconnected networks. OK Cancel ernet Protocol Version 4 (TCP/IPv4) Properties eneral Alternate Configuration You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings. OUse the following IP address: IP address: Subnet mask: Default DNS server addresses: Prefered DNS server: Atternate DNS server: Atternate DNS server: Control Protocol Protocol Protocol Protocol Atternate DNS server: Control Protocol Protocol Atternate DNS server: Control Protocol Control Pro	Transmission Cortxel Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks. OK Cancel ernet Protocol Version 4 (TCP/IPvd) Properties ernet Protocol Version 4 (TCP/IPvd) Properties eneral Alternate Configuration (or can get P settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings. © Obtain an IP address automatically O use the following IP address: IP address: Subnet mask: Default gateway: @ Obtain DNS server addresses: Preferred DNS server: Aternate DNS server: Aternate DNS server: Validate settings upon exit Advanced	Install Unir	nstall		Prop	oerties	
wide area network protocol that provides communication across diverse interconnected networks.         OK       Cancel         ermet Protocol Version 4 (TCP/IPv4) Properties         eneral       Alternate Configuration         You can get IP settings assigned automatically if your network administrator for the appropriate IP settings.         Obtain an IP address automatically         Use the following IP address:         Subnet mask:         Default gateway:         Obtain DNS server address automatically         Ouse the following DNS server addresses:         Prefered DNS server:         Atternate DNS server:         Atternate DNS server:	wide area network protocol that provides communication across diverse interconnected networks.       OK       Cancel       OK       Cancel   emeral Alternate Configuration       rou can get IP settings assigned automatically if your network administrator       of obtain an IP address automatically       Ouse the following IP address:       P address:       Submet mask:       Submet mask:       Obtain DNS server addresses:       Preferred DNS server:       Atemate Settings upon exit						
Alternate Configuration         You can get IP settings assigned automatically if your network administrators         Bit capability. Otherwise, you need to ask your network administrators         Image: Configuration of the following IP address:         IP address         I	Internate Configuration       (or, can get IP settings assigned automatically if your network administrator for the appropriate IP settings.       IP address:       IP address:       Subnet mask:       Obtain DNS server address automatically       Observer:       Attranate DNS server:       Attranate DNS server:       Attranate DNS server:       Validate settings upon exit			ок		Can	cel
Alternate Configuration         You can get IP settings assigned automatically if your network administrators         Bit capability. Otherwise, you need to ask your network administrators         Image: Configuration of the following IP address:         IP address         I	Internate Configuration       (or, can get IP settings assigned automatically if your network administrator for the appropriate IP settings.       IP address:       IP address:       Subnet mask:       Obtain DNS server address automatically       Observer:       Attranate DNS server:       Attranate DNS server:       Attranate DNS server:       Validate settings upon exit						
Alternate Configuration         You can get IP settings assigned automatically if your network administrators         Bit capability. Otherwise, you need to ask your network administrators         Image: Configuration of the following IP address:         IP address         I	Internate Configuration       (or, can get IP settings assigned automatically if your network administrator for the appropriate IP settings.       IP address:       IP address:       Subnet mask:       Obtain DNS server address automatically       Observer:       Attranate DNS server:       Attranate DNS server:       Attranate DNS server:       Validate settings upon exit						
Out of the settings assigned automatically if your network supports     this capability. Otherwise, your need to ask your network administrator     for the appropriate IP settings.     Obtain an IP address automatically     Outse the following IP address:         IP address:         Subnet mask:         I     Default gateway:         Outse the following DNS server addresses:     Preferred DNS server:         Atternate DNS server:         Attern	Concernence compared automatically if your network supports     fine capability. Otherwise, you need to ask your network administrator     for the appropriate IP settings.     Ouse the following IP address:     IP address:     IP address:     IP address:     ID add	ernet Protocol Version 4 (TCP/IPv	4) Propert	ies			
Obtain DNS server addresses:     Preferred DNS server:     Atternate DNS server:	bic capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.     O bata in an IP address automatically     Use the following IP address:     IP	eneral Alternate Configuration					
Use the following IP address: IP address: Subnet mask: Default gateway: Obtain DNS server address automatically Obta the following DNS server: Preferred DNS server: Alternate DNS server:	Use the following IP address:  P address:  Subnet mask: Default gateway:  O bitain DNS server address automatically  Use the following DNS server addresses: Preferred DNS server:  Atternate DNS server:  Validate settings upon exit  Advanced	this capability. Otherwise, you need for the appropriate IP settings.	to ask your	f your n netwo	etwor rk adm	k suppo inistrato	rts vr
IP address:	IP address:	0	ally				
Subnet mask: Default gateway:  Obtain DNS server address automatically Ouse the following DNS server addresses: Prefered DNS server: Alternate DNS server:	Subnet mask:	-					
Default gateway:	Default gateway:						
Obtain DNS server address automatically     Ouse the following DNS server addresses:     Preferred DNS server:     Atemate DNS server:	Obtain DNS server address automatically     Use the following DNS server addresses:     Preferred DNS server:     Aternate DNS server:     Aternate DNS server:     Advanced						
Use the following DNS server addresses: Preferred DNS server: Alternate DNS server:	Use the following DNS server addresses:       Preferred DNS server:       Alternate DNS server:       Alternate DNS server:       Validate settings upon exit   Advanced	Default gateway:					
Preferred DNS server:	Preferred DNS server:        Alternate DNS server:        Validate settings upon exit     Advanced	Obtain DNS server address aut	omatically				
Alternate DNS server:	Alternate DNS server:	Use the following DNS server as	ddresses:				
	Validate settings upon exit Advanced	Preferred DNS server:					
Validate settings upon exit Advanced	Auvalueu	Alternate DNS server:	1.1				
	OK Cancel	Validate settings upon exit					
	OK Cancel				Ad	vanced	




Continue to the next steps if you are using PPPoE connection.

- **NGLISH**
- Return to the Network and Sharing Center and then click Set up a new connection or network.

7. Select **Connect to the Internet** and click **Next**.

- 8. Select **Broadband (PPPoE)** and click **Next**.
- 9. Follow the next onscreen instructions to complete the setup.



✓ Ŏ Search Co

vork information and set up con

are currently not connected to any networks

Set up a new connection or network Set up a broadband, dial-up, or VPN connection; or set up a router or access point.

↑ 💆 « Network and Internet → Network and Shi

Change advanced sharing

View your basic netw

View your active ne

.....

Broadband (PPPOE) Connect using DSL or cable that requires a user name and password.	
Bnew connection options that this computer is not set up to use	


# Configuring a static IP network connection To configure a static IP network connection:

- 1. Repeat steps 1 to 4 of the previous section.
- 2 Click Use the following IP address.
- 3. Enter the IP address, Subnet mask and Gateway from your service provider.
- 4. If needed, enter the preferred DNS Server address and alternative address.
- 5. When done, click **OK**.

Internet Protocol Version 4 (TCP/IPv4	1) Properties ×
General	
You can get IP settings assigned auto this capability. Otherwise, you need t for the appropriate IP settings.	
Obtain an IP address automatica	ally
• Use the following IP address:	
IP address:	192 . 168 . 128 . 2
Subnet mask:	255.255.255.0
Default gateway:	192 . 168 . 128 . 2
Obtain DNS server address auto	matically
Use the following DNS server ad	dresses:
Preferred DNS server:	· · · · ·
Alternate DNS server:	
Validate settings upon exit	Advanced
	OK Cancel

# Wi-Fi connection (on selected models only)

Connect your computer to the Internet through a wireless connection.



Ø

To increase the range and sensitivity of the wireless radio signal, connect the external antennas to the antenna connectors on the ASUS WLAN Card.

Т	
S	
U	
Ζ	
ш	

# Chapter 5

# Troubleshooting

This chapter presents some problems you might encounter and the possible solutions.

# ? My computer cannot be powered on and the power LED on the front panel does not light up.

- Check if your computer is properly connected.
- Check if the wall outlet is functioning.
- Check if the Power Supply Unit is switched on. Refer to the section Turning your computer ON in Chapter 1.

# ? My computer hangs.

- Do the following to close the programs that are not responding:
  - 1. Simultaneously press <Alt> + <Ctrl> + <Delete> keys on the keyboard, then click **Task Manager**.
  - 2. Select the program that is not responding, then click **End Task**.
- If the keyboard is not responding, press and hold the Power button on the top of your chassis until the computer shuts down. Then press the Power button to turn it on.

# ? I cannot connect to a wireless network using the ASUS WLAN Card (on selected models only)?

- Ensure that you enter the correct network security key for the wireless network you
  want to connect to.
- Connect the external antennas (optional) to the antenna connectors on the ASUS WLAN Card and place the antennas on the top of your computer chassis for the best wireless performance.

# ? The arrow keys on the number key pad are not working.

Check if the Number Lock LED is off. When the Number Lock LED is on, the keys on the number key pad are used to input numbers only. Press the Number Lock key to turn the LED off if you want to use the arrow keys on the number key pad.

# ? No display on the monitor.

- Check if the monitor is powered on.
- Ensure that your monitor is properly connected to the video output port on your computer.
- If your computer comes with a discrete graphics card, ensure that you connect your monitor to a video output port on the discrete graphics card.
- Check if any of the pins on the monitor video connector is bent. If you discover bent pins, replace the monitor video connector cable.
- Check if your monitor is plugged to a power source properly.
- Refer to the documentation that came with your monitor for more troubleshooting information.

# ? When using multiple monitors, only one monitor has display.

- Ensure that the both monitors are powered on.
- During POST, only the monitor connected to the VGA port has display. The dual display function works only under Windows.
- When a graphics card is installed on your computer, ensure that you connect the monitors to the output port on the graphics card.
- Check if the multiple displays settings are correct.

## ? My computer cannot detect my USB storage device.

- The first time you connect your USB storage device to your computer, Windows
  automatically installs a driver for it. Wait for a while and go to My Computer to
  check if the USB storage device is detected.
- Connect your USB storage device to another computer to test if the USB storage device is broken or malfunctions.

# *? I want to restore or undo changes to my computer's system settings without affecting my personal files or data.*

You can use Windows<sup>\*</sup> 10 **Refresh your PC without affecting your files** recovery option to restore or undo changes to your computer's system settings without affecting your personal data such as documents or photos. To use this recovery option, click **Settings > Update & recovery > Recovery** from the Start menu, select **Refresh your PC without affecting your files**, and click **Get started**.

#### ? The picture on the HDTV is distorted.

- It is caused by the different resolutions of your monitor and your HDTV. Adjust the screen resolution to fit your HDTV. To change the screen resolution:
  - From the Start menu, click **Settings** > **System** > **Display**.

#### ? My speakers produce no sound.

- Ensure that you connect your speakers to the Line out port (lime) on the front panel or the rear panel.
- Check if your speak is connected to an electrical source and turned on.
- Adjust your speakers' volume.
- Ensure that your computer's system sounds are not Muted.
  - If it is muted, the volume icon is displayed as to enable the system sounds, click from the Windows notification area, then click solution.
  - If it is not muted, click 💷 and drag the slider to adjust the volume.
- Connect your speakers to another computer to test if the speakers arer working
  properly.

#### ? The DVD drive cannot read a disc.

- Check if the disc is placed with the label side facing up.
- Check if the disc is centered in the tray, especially for the discs with non-standard size or shape.
- Check if the disc is scratched or damaged.

#### ? The DVD drive eject button is not responding.

- 1. From the Start menu, click **File Explorer**.
- 2. Right-click PVD RW Drive, then click **Eject** from the menu

# ENGLISH

#### Power

Problem	Possible Cause	Action
No power (The power indicator is off)	Incorrect power voltage	<ul> <li>Set your computer's power voltage switch to your area's power requirements.</li> <li>Adjust the voltage settings. Ensure that the power cord is unplugged from the power outlet.</li> </ul>
	Your computer is not turned on.	Press the power key on the front panel to ensure that your computer is turned on.
	Your computer's power cord is not properly connected.	<ul> <li>Ensure that the power cord is properly connected.</li> <li>Use other compatible power cord.</li> </ul>
	PSU (Power supply unit) problems	Contact the ASUS Service Center about installing another PSU on your computer.

# Display

Problem	Possible Cause	Action
No display output after turning the computer on (Black screen)	The signal cable is not connected to the correct VGA port on your computer.	<ul> <li>Connect the signal cable to the correct display port (onboard VGA or discrete VGA port).</li> <li>If you are using a discrete VGA card, connect the signal cable to the discrete VGA port.</li> </ul>
	Signal cable problems	Try connecting to another monitor.

## LAN

Problem	Possible Cause	Action
Cannot access the Internet	The LAN cable is not connected.	Connect the LAN cable to your computer.
	LAN cable problems	Ensure the LAN LED is on. If not, try another LAN cable. If it still does not work, contact the ASUS service center.
	Your computer is not properly connected to a router or hub.	Ensure that your computer is properly connected to a router or hub.
	Network settings	Contact your Internet Service Provider (ISP) for the correct LAN settings.
	Problems caused by the anti- virus software	Close the anti-virus software.
	Driver problems	Reinstall the LAN driver

# Audio

Problem	Possible Cause	Action
No Audio	Speaker or headphone is connected to the wrong port.	<ul> <li>Refer to your computer's User Guide for the correct port.</li> <li>Disconnect and reconnect the speaker to your computer.</li> </ul>
	Speaker or headphone does not work.	Try using another speaker or headphone.
	The front and back audio ports do not work.	Try both the front and back audio ports. If one port failed, check if the port is set to multi-channel.
	Driver problems	Reinstall the audio driver

# System

Problem	Possible Cause	Action
	Too many programs are running.	Close some of the programs.
System speed is too slow	Computer virus attack	<ul> <li>Use an anti-virus software to scan for viruses and repair your computer.</li> <li>Reinstall the operating system.</li> </ul>
The system often hangs or freezes.	Hard disk drive failure	<ul> <li>Send the damaged hard disk drive to ASUS Service Center for servicing.</li> <li>Replace with a new hard disk drive.</li> </ul>
	Memory module problems	<ul> <li>Replace with compatible memory modules.</li> <li>Remove the extra memory modules that you have installed, then try again.</li> <li>Contact the ASUS Service Center for assistance.</li> </ul>
	There is not enough air ventilation for your computer.	Move your computer to an area with better air flow.
	Incompatible softwares are installed.	Reinstall the OS and reinstall compatible softwares.

### CPU

Problem	Possible Cause	Action
Too noisy right after turning on the computer.	Your computer is booting up.	It is normal. The fan runs on its full speed when the computer is powering on. The fan slows down after entering the OS.
	The BIOS settings have been changed.	Restore the BIOS to its default settings.
	Old BIOS version	Update the BIOS to the latest version. Visit the ASUS Support site at <b>https:// www.asus.com/support</b> to download the latest BIOS versions.
Computer is too noisy when in use.	The CPU fan has been replaced.	Ensure that you are using a compatible or ASUS-recommended CPU fan.
	There is not enough air ventilation for the computer.	Ensure that your computer is working in an area with good air flow.
	The system temperature is too high.	<ul> <li>Update the BIOS.</li> <li>If you know how to reinstall the motherboard, try to clean the inner space of the chassis.</li> <li>Contact the ASUS Service Center for assistance.</li> </ul>



If the problem still persists, refer to your Desktop PC's warranty card and contact the ASUS Service Center. Visit the ASUS Support site at <u>https://www.asus.com/support</u> for the service center information.

Т	
S	
G	
Ζ	
ш	


# Appendix Using Windows<sup>®</sup> 10

# Starting for the first time

When you start your computer for the first time, a series of screens appear to guide you in configuring the basic settings of your Windows<sup>®</sup> 10 operating system.

#### To start your Desktop PC for the first time:


When you start your computer for the first time, a series of screens appear to guide you in configuring the basic settings of your Windows<sup>®</sup> 10 operating system.

#### To start your Desktop PC for the first time:

- 1. Press the power button on your Desktop PC. Wait for a few minutes until the setup screen appears.
- From the setup screen, pick your region and language that you want to use on your desktop PC.
- 3. Carefully read the License Terms, then tap I Accept.
- 4. Follow the onscreen instructions to configure the following basic items:
  - Personalize
  - Get online
  - Settings
  - Your account
- Wait until Windows® 10 finishes installing the apps and system settings. After the installation, the Windows® 10 desktop appears.

# Using the Windows<sup>®</sup> 10 UI

The Windows<sup>\*</sup> 10 User Interface (UI) includes the favorite Start menu and the tiled-formatted Start screen. It includes the following features you can use while working on your Desktop PC.



#### Start menu

Windows® 10 brings back the Start menu with some enhancements, such as the space that you can customize with your favorite apps, people, or websites.

You can launch the Start menu in two ways:

- Click the Start button from the lower-left corner of the taskbar.
- Press the Windows® Start key 📕 on your keyboard.


#### Pinning apps to the Start screen or taskbar

#### To pin an app to the Start screen or taskbar:

- 1. From the Start menu, click **All apps**, then select the app that you want to pin.
- 2. Click **Pin to Start** or **Pin to taskbar** to pin your selected app to the Start screen or taskbar. You can also drag then drop an app to the Start Screen or taskbar to pin it.

#### Start screen

The Start screen, which appears together with the Start menu, helps organize all the apps you need in just one place. The apps on the Start screen are displayed on tiled-format for easy access.



#### Moving apps on the Start screen

You can move apps from the Start screen simply through dragging and dropping the app to your preferred location.

#### Unpinning apps from the Start screen

To unpin an app from the Start screen, right-click on the app to activate its settings bar then click **Unpin from Start**.

#### Taskbar

Windows® 10 comes with the standard taskbar, which keeps all your currently running apps or items in the background.


#### Unpinning apps from the taskbar

- 1. From the Start screen or taskbar, right-click the app you want to unpin.
- 2. Click **Unpin from Start** or **Unpin this program from taskbar** to remove the app from the Start screen or taskbar.

#### **Using the Task View**


When you have several running apps, you can click  $\bigcirc$  from the taskbar to display all your running apps, and click on an app or item to launch it.

If task view is disabled, click **Show Task View button** to display the task view icon <sup>(1)</sup>.



#### **Snap feature**

The Snap feature displays about four apps or more in one screen, allowing you to work or switch among apps.



#### **Using Snap**

Use your Desktop PC's mouse or keyboard to activate Snap onscreen.

#### Using your mouse

- a) Launch an app, then drag and release on a screen corner to snap it in place.
- b) Snap another app to your preferred location on the screen.

#### Using your keyboard

- a) Launch an app, press and the arrow keys to select the direction where you want to snap the app in place.
- b) Snap another app using 📲 and the arrow keys.

# **Keyboard shortcuts**

Using your keyboard, you can also use the following shortcuts to help you launch apps and navigate Windows<sup>\*</sup> 10.

•	Switches between the Start screen and the last running app
■ + <d></d>	Launches the desktop
■ + <e></e>	Launches File Explorer
■ + <f> or ■ + <w></w></f>	Activates the File search function
<b>■</b> + <h></h>	Launches Share
<b>a</b> + < >	Launches Settings
• + <k></k>	Launches Media Connect
• + <l></l>	Activates the Lock screen
•••+ <m></m>	Hides all currently active screens to the taskbar
• + <p></p>	Your desktop PC is mirrored to your secondary monitor
■ + <q></q>	Launches Cortana
•• + <r></r>	Launches the Run window
<b>u</b> + <u></u>	Launches Ease of Access Center
# + <x></x>	Launches a menu box of Windows tools

<b>a</b> + <+>	Launches the magnifier and zooms in your screen.	
<b>a</b> + <->	Zooms out your screen.	
+ <enter></enter>	Opens the Narrator Settings.	

#### Removing everything and reinstalling Windows® 10


Restoring your PC to its original factory settings can be done using the Remove everything and reinstall options in PC Settings. Refer to the steps below to use this option.



Back up all your data before using this option.

This process may take a while to complete.

- 1. From the Start menu, click **Settings** > **Update & security** > **Recovery**.
- 2. Scroll down to view the **Remove everything and reinstall Windows** option. Under this option, click **Get started**.



3. Follow the onscreen instructions to complete the reinstallation and reset process.

# **ASUS contact information**

## ASUSTeK COMPUTER INC.

Address Telephone Fax Web site 1F., No. 15, Lide Rd., Beitou Dist., Taipei City 112, Taiwan +886-2-2894-3447 +886-2-2890-7798 https://www.asus.com/

#### **Technical Support**

Telephone Online support +86-21-38429911 https://qr.asus.com/techserv

#### **ASUS COMPUTER INTERNATIONAL (America)**

Address Telephone Fax Web site 48720 Kato Rd., Fremont, CA 94538, USA +1-510-739-3777 +1-510-608-4555 https://www.asus.com/us/

#### **Technical Support**

Support fax Telephone Online support +1-812-284-0883 +1-812-282-2787 https://qr.asus.com/techserv

#### **ASUS COMPUTER GmbH (Germany and Austria)**

Address Web site Online contact Harkortstrasse 21-23, 40880 Ratingen, Germany https://www.asus.com/de https://www.asus.com/support/Product/ContactUs/Services/ guestionform/?lang=de-de

#### **Technical Support**

Telephone (DE) Telephone (AT) Online support +49-2102-5789557 +43-1360-2775461 https://www.asus.com/de/support