

ATR2100x-USB Cardioid Dynamic USB/XLR Microphone

User Manual

Contents

- Introduction & features 2
- Setting up your microphone with pivot mount & desk stand 3
 - Preliminary setup with MacOS Mojave 4
 - Advanced setup with MacOS Mojave 7
 - Preliminary setup with Windows 10 9
 - Advanced setup with Windows 10 11
 - Using headphones 15
 - Selecting software 15
 - Setting your software levels 15
 - Positioning your microphone 15
 - XLR Operation 15
 - Protecting your microphone 15
 - Specifications 16
 - Warranty 17



audio-technica

Compliance with FCC rules (USA only)

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Canada only

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme á la norme NMB -003 du Canada.

Thank you for buying the Audio-Technica ATR2100x-USB cardioid dynamic USB/XLR microphone. Equipped with both USB-C and XLR outputs, this digital/analog mic is designed both for live performance and digitally capturing music or any acoustic audio source using your favorite recording software.

The ATR2100x-USB offers high-quality articulation and intelligibility perfect for home studio recording, field recording, podcasting, voice over, and on-stage use. Its cardioid polar pattern reduces pickup of sounds from the sides and rear, improving isolation of desired sound source.

The microphone also features a built-in headphone jack with volume control that allows you to directly monitor your microphone's output during recording. The microphone's focused pickup pattern delivers excellent off-axis rejection, while its A/D converter with up to 24-bit, 192 kHz sampling rate ensures clear, articulate sound reproduction.

Audio-Technica's state-of-the-art design and manufacturing techniques ensure that the microphone complies with the company's renowned consistency and reliability standards.

Features

- · Handheld dynamic microphone with USB digital output and XLR analog output
- USB output connects to your computer for digital recording, while the XLR output connects with your sound system's conventional microphone input for use in live performance
- Smooth, extended frequency response ideally suited for podcasting, home studio recording, field recording, voice over, and on-stage use
- · Built-in headphone jack allows you to directly monitor your microphone's output without audible delay
- Adjust headphone volume with easy-to-use controls on the bottom of the microphone
- High-quality A/D converter with up to 24-bit, 192 KHz sampling rate
- Compatible with Windows and Mac
- Low-mass diaphragm provides excellent frequency response
- Cardioid polar pattern reduces pickup of sounds from the sides and rear, improving isolation of desired sound source
- Tripod desk stand with folding legs for secure, easily portable tabletop use
- · Pivoting, threaded stand mount attaches securely to the supplied tripod or to a conventional microphone stand
- USB-C to USB-A, USB-C to USB-C and XLR cables included
- Durable metal construction for long-lasting performance
- On/off switch functions for both USB and analog operation

ATR2100x-USB Setup



- Screw the microphone stand clamp onto the threaded portion of the desk stand. The front of the microphone should be facing the A-T logo on the desk stand.
- Install the microphone into the stand clamp, with ON/OFF switch facing up.
- Extend the tripod legs to provide a wide, secure base, and place the tripod desk stand on a flat surface.
- Use a screwdriver or coin to loosen/tighten the pivot screws for angle adjustment.
- 5 For digital use, plug one of the provided USB cables into the base of the microphone then connect the other end of the cable to your digital recording device.

When connecting the microphone to a USB-C port, you must use a USB On-The-Go (USB OTG) cable like the one included.

For analog use, plug the provided XLR cable into the base of the microphone then connect the other end of the cable to your analog audio device.

6

When using with equipment that includes a built-in mic, consult that device's user guide for instructions on disabling its mic.

Optional headphone monitoring: Connect headphones with 3.5 mm (1/8") plug into base of microphone. Use the dial to control volume.

Preliminary setup with MacOS Mojave

NOTICE Regarding MacOS Catalina

With the release of MacOS Catalina, Apple has introduced restrictions on using non-Apple software. Unless the recording application is officially supported to run under MacOS Catalina, you will not be able to access the microphone even if it shows up as a sound input device!

If you are using an older version of MacOS, your computer will automatically recognize the USB device and install the appropriate driver.

If you are using MacOS Mojave, you must enable software access to the microphone, using the security and privacy settings.

1. Connect the ATR2100x-USB microphone to an open USB port on the Mac (Type A or Type C).

Open the system preferences by clicking the Apple logo in the upper left corner of the menu bar and selecting System Preferences. Alternatively, you can click on the gear icon in the dock. Click the Loudspeaker icon to open the sound preferences.

Ś	Finder	File	Edit	View	Go
Ał	out This	Mac			
Sy	stem Pref	erenc	es		
Ap	op Store			3 upda	ates
Re	cent Item	c			1



Click the Apple Logo and select System Preferences

Click the Loudspeaker icon to open the sound preferences

2. By default the Mac selects the internal microphone as the sound input device. When the ATR2100x-USB is plugged in, the Mac assumes that it is the desired input device and automatically selects it.

Verify that the ATR2100x-USB is highlighted.

The input volume for the microphone can be adjusted by moving the input slider and watching the level meter while speaking into the microphone. Setting the level too low will not provide enough input signal to your recording application. Setting it too high can overload the input to the recording application resulting in clipping or distortion.

Note: The output volume slider controls the Mac's speaker or headphone jack output and does not affect the input sound level. This slider replicates the volume control associated with the small speaker icon in the menu bar and the volume controls on the keyboard.

	Sc	ound		Q Search
	Sound Effects	Output	Input	
Select a device for sound i	nput:			
Name			Туре	
Internal Microphone			Built-in	
ATR2100x-USB Microphone	10		USB	
Settings for the selected de	vice:			I
input volume	Ч		· · · · ·	
Input leve		1111		

Preliminary setup with MacOS Mojave (continued)

 Because the ATR2100x-USB Microphone has a built-in headphone output, the Mac selects it as the output device. Should you desire to use the internal speakers for playback audio, click the Output tab and choose the desired output device.

The balance control sets the left to right balance in the output device.

The Output volume controls the playback level from the Mac. It is the same as clicking on the small speaker icon in the menu bar and adjusting volume or using the keyboard controls.

	Sound	Q Search
	Sound Effects Output	Input
Select a device for sound ou	itput:	
Name		Type
Internal Speakers Pro Tools Aggregate I/O	1	Built-in Aggregate device
ATR2100x-USB Microphone		USB
Settings for the selected devi Balance:	ice:	right
Settings for the selected devi	ce:	right

With recent updates to MacOS Mojave and the latest MacOS Catalina, Apple implemented a privacy setting allowing you to control which apps have access to the microphone.

If you are using MacOS Mojave, you must enable software access to the microphone, using the security and privacy settings.

 In order to use the ATR2100x-USB microphone with certain applications you need to verify that the apps are enabled to have access to the microphone.

Open the system preferences and click on the Security and Privacy icon.



Preliminary setup with MacOS Mojave (continued)

To make changes, you will need to unlock the padlock on the Security and Privacy window by entering your user name and password.

Scroll down to make certain the apps you want to use the microphone with are enabled. If not, use the switch slider associated with the App to turn it on.

••• < >	Sec	urity & Priva	су	Q Search	
	System Prefe Privacy prefe Enter your pas	erences is try rences. ssword to allo	ying to unlock Sec ow this.	urity &	
Cont	User Name: Password:				
📆 Cale			Cancel	nlock	
Reminders		Captu	ıre		
Photos		Studi	o One		
Camera		~			
Microphone					
Accessibility					
Full Disk Access					
Authenticating				Advanced	2

3. Click the microphone icon and verify that a check mark appears next to the applications that need access to the microphone.

Make certain to click the lock to lock it after making the changes.



Advanced setup with MacOS Mojave

Advanced Sound Settings

 At this point the Mac is set up to use the ATR2100x-USB microphone as the input device and your selection as the output device. The sample rate is set for the default value (44.1 KHz CD Quality). However, additional settings are available that enable you to change the audio sampling rate and individually adjust left and right input signal levels if you desire.

To access these settings, open a new finder window and navigate to "Applications—Utilities" and double-click the Audio MIDI Setup application.

		🔀 Utilities	
K >	View Group	Action Share Edit Teos Dropbox	Search
Favorites Recents Recents SteveSavanyu SteveSavanyu Dosktop Dropbox AiDrop Donwinads Aidentine	Siri Siyje Sype Sype Sypectest Stocks Studio One A Studie Expander System Preferences / TextEdt Tim Mohine Tom HOME Tom Mohine Tom Mohine Tom Mohine	Adobe Creatil. d Experience Adobe Firshstall Manger Adobe Firshstall Manger Adobe Minister Boot Camo Assistant CodorSync Utility Console Digital Color Meter Di	
Documents Creative Cloud Files	ViistedWave UniversalControl Utilities Voice Memos	 ● Grapher ➢ HP Utility ▶ & Keyshain Access 	 More
	1 of 28	selected, 394.26 GB available	

Audio MIDI Setup

2. A list of audio devices appears on the left side and the adjustable settings for the selected device appear on the right.

The ATR2100x-USB appears as two separate devices. One is an input device (2 ins / 0 outs) while the other represents its output (0 ins / 2 outs).

Clicking the input device (2 ins / 0 outs) shows the current settings.

The Format section contains the sample rate settings.

The Master Stream section allows you to individually adjust the microphone signal levels for the left and right audio inputs.

	•	ł	Audio Devices					
C H	Built-in Microphone 2 ins / 0 outs Built-in Output 0 ins / 2 outs	ATR2100x	-USB Microphone 1 rce: Default	Output				?
* •‡	ATR2100x-USB Microph 2 ins / 0 outs	Source: Di	efault 2 ch 16-bit Integer 44.1 k	Hz				
4	0 ins / 2 outs	Channel Volume		Specify	the car	inle rate i	and hit a	denth
• 🕀	0 ins / 2 outs	▼Master Strea	, am	Specify	uic aui	ipic fate i		acpui
× G	After Effects 13.7.2	Master						
-	0 ins / 0 outs	Front Left	0-		0.61	10.0		
• 🕀	0 ins / 0 outs	Front Right			0.61	10.0		
• 🚭	Premiere Pro 8.0 0 ins / 0 outs							

Select input version ATR2100x-USB with 2 ins / 0 outs

Advanced setup with MacOS Mojave (continued)

3. The ATR2100x-USB is capable of very high-quality recording and supports sample rates of up to 192 KHz. In some situations higher sample rates can provide better results. However, as the sample rate increases, the file size becomes much larger.

If you are recording voice-overs for video or music that will be synchronized with video, the default sample rate needs to be changed from 44.1 KHz to 48 KHz.

To change the sample rate, click the drop-down arrows next to the Format box. A sub window opens listing available sample rates. Click on the desired one to choose it and close the sub-window.

Remember that the selected sample rate must match the value set in your recording application or you will hear pops and clicks in the recorded audio.



Preliminary setup with Windows 10

If you are using an older version of Windows, your computer will automatically recognize the USB device and install the appropriate driver.

The first time you plug the microphone in, you may see a message that new hardware has been found, or you may see a driver software installed notice. After the first time, you will not see any of these as the computer has already installed the necessary drivers for a USB microphone.

When the ATR2100x-USB microphone is connected, Windows 10 will automatically select it as the input and output device.

1. To verify or make changes click the Start window and click settings (the gear).



2. When the settings window opens, Click "System."

			Window	vs Settin	igs		
			Find a setting		P		
₽	System Dializy, signal, notifications, prover	-	Devices Bluetouth, pinters, mouse	۵	Phone Link your Android, Phone	•	Network & Internet Wi-Fi, aligtane mode, VPN
ø	Personalization Eachproved, lock advance, same	E	Apps Uninitiali, defaulta, optional features	R	Accounts Now accounts, amail, syme, work, family	\$₽	Time & Language Speech, region, date
8	Gaming Game bac captures, broadcasting, Game Mode	œ	ase of Access accesses magnifier, high as	Q	Search Find my film, permissions	0	Cortana Cortana lenguage, permissions, notifications
A	Privecy Location, camera, microphone	С	Update & Sea A. Mindows Update, M. Ku Jacobup				

Preliminary setup with Windows 10 (continued)

3. When the System window opens, in the left column, click "Sound."



4. The Sound tab opens showing the active input and output device which should be the USB microphone.

To use the computer speakers as your output device, click "Choose your output device" and in the drop-down menu choose the desired item.



At this point, your computer is set up to use the ATR2100x-USB microphone as the audio input device and whatever you chose as the audio output device. However, in the recent versions of Windows 10, Microsoft has instituted some additional privacy settings, allowing users to control which apps and programs have access to the microphone. Refer to the section on privacy for more information.

There are additional settings available for the microphone, allowing you to set the input level, change the sampling rate and manage other aspects of the audio. Refer to the next section for more details.

Advanced setup with Windows 10

At this point Windows 10 is set up to use the ATR2100x-USB microphone as the input and output device. The sample rate is set for the Windows default (44.1 KHz CD Quality). However, additional settings are available, including input level and sampling rate.

1. To access these settings, click "Sound Control Panel."



- 2. When the Sound Control Panel opens, select the "Recording" tab and select the ATR2100x-USB microphone.
- 3. Click "Properties."
- 4. Click the Levels tab and move the slider to the right or left to set the input gain for the microphone. Setting it too low will not provide enough signal to your recording application. Setting it too high can cause the recording application to distort.

Note that this level setting is different from the volume control slider on the main sound settings window.

 Settings University 					← Settings	
A 14444				anoyou .		
te nome		Sound			Home Home	
Find a setting	p	Output		10.00 M	Find a setting	
System	9 Seured		×		System 9	
	Pleybeck Receipting Sounds of	Communications	Micr V		C Display	along recently 2004
Display	Select a recording device below	e to modify its settings	use different sound	Cardo a	40. formed	 Morphane Pro
10 Sound	Manaphane ARR/100-USE Ma	anghane	app volumes and de			Contra Contra Co
Notifications (Microphone Array			Designed	Notifications #	Moophone
 revencations c 	Reality Audio			_	J Focus assist	1
<i>Focus assist</i>	Stereo Max Restaurs) Audio			Q	O Power & sleep	
D Power & sleep	All and a second s			121 4.14	CD Balley	
D. Ramon				6		
- coney				-	C Storage	
⇒ Storage				Conc	C8 Tablet mode	1
Tablet mode	Contigue	Set Default (*) Properties			H Multitasking	
E Multitaskino		OC Cancel Act			Projecting to this I	R
		Microphone (ATR2100	558 A		Y. Gaust appricate	
Projecting to t	his PC	Certain apps may be set u one selected here. Outon	p to use diversely sound size and volumented of de		ra Joana expensesce	
X Shared experie	ences	sound options.			D Clipboard	
* Circheard		Device properties			✓ Remote Desktop	
		System Department	System Capital Capi	System 1 Diple 1 Diple <td>Option Image: Section of the section of t</td> <td>System</td>	Option Image: Section of the section of t	System

Advanced setup with Windows 10 (continued)

5. The ATR2100x-USB is capable of very high-quality recording and supports sample rates of up to 192 KHz. In some situations higher sample rates can provide better results. However, as the sample rate increases, the file size becomes much larger.

If you are recording voice-overs for video or music that will be synchronized with video, the default sample rate needs to be changed from 44.1 KHz to 48 KHz.

To change the sample rate, click the Advanced tab. The default sample rate (44100 Hz CD Quality) is shown in the drop-down box. Click the drop-down and choose the desired sample rate.

C.	← Settings	a de sua	- 0 ×
		Sound	
869 W	Find a settin	P Output	Related Settings Bluetooth and other devices
	System	Brown × Reduct REPERT South Computation	Sound Control Panel
5000	C Display	Monphone Program X Sifferent sound devices than the	Microphone privacy settings
P	44 Sound	General Laten Levels Adversed	Ease of Access audio settings
Cascing	Notificati	15 8 Self-the same wate and bit depth to be used when running in shared mode.	Have a question?
G	J Focus ass	t 2 manner 24 bit, 41100 no dhudia Charter V 2 manner 18 bit, 41100 no dhudia Charter V 1 manner 18 bit, 41100 no dhudia Charter V	Set up a microphone Fix sound problems
927 Aug	O Power&:	Pep 2 Calences, 16 bit, 20000 to Convelo Quellos 2 Converso, 16 bit, 20000 to Convelo Quellos E Converso, 24 bit, el 2000 to Convelo Converso 2 Converso, 24 bit, el 2000 to Converso Converso 2 Converso Converso Converso Converso Converso Converso Converso 2 Converso Converso Converso Converso Converso Converso Converso Converso 2 Converso Convers	Get help
6	Battery	2 deame, 24 bit, 1000 tit (Studio Quality) 2 deame, 24 bit, 10000 tit (Studio Quality)	Make Windows better
-310 9-040	Cit Stotage		Give us feedback
	H Multitask		
	67 Projecting	to this P OC Great Asia different and devices than the	
	X Shared e	we services were consumer approximes and sizes in advanced sound options.	
	Clipboard	Device properties	
	> Remote 0	estrop 0.	

6. Leaving the "Exclusive Mode" boxes checked allows the recording application to take control of the microphone. This will set the sample rate correctly based on the recording project settings.

When the sample rate is changed, a "Device in use" warning dialog box appears letting you know that a change has been made that may affect other applications (non-exclusive) that might be using the microphone.

Click "Yes" to continue and use the new sample rate.

L THEFT		Sound		
Find a setting		Output		Related Settings
ystern	9 Sevel			buences and other devices
	Heated Recording Sounds	Communications	Micr v	Sound Control Panel
Display	Murphers Prepart	1	× different sound devices than the	Microphone privacy settings
0 Sound	General Later Levels	Advanced	volumes and devices in advanced	Ease of Access audio settings
	Default Formal			
Notifications (Select the sample rat in shared mode.	ie and bit depth to be used when running		Have a question?
Focus assist	2 channel, 24 bit, 15	10000 Hz (Studio Quelity) V	900	Set up a microphone
Prover & sleep	Estudie Made			Fix sound problems
	PAter application	o to take exclusive combol of this device	Q Derice	In She
 Battery 	Don month	an approache promp		
Storage			<u> </u>	Ine encode is being used by another application. In you continue, that application may stop working. Do you want to continue?
Tablet mode	1			
		-		Dave No
Multitasking	Restore Delauits		- ×	
P Projecting to t	this PC	OK Canon April	different sound devices than the	
Thought connection		one seacing mine costs	pp folumes and devices in advanced	-
, anales experi	617.65	Device properties		
Clipboard		Test your microshope		
Remote Deskt	cp	D		
		A Troubleshoot	•	
ADOUR		Manager and designs		
		manage sound devices		

Advanced setup with Windows 10 (continued)

With recent updates to Windows 10, Microsoft has included a privacy setting allowing you to control which apps have access to the microphone.

In order to use the ATR2100x-USB microphone with certain applications you need to verify that the apps are enabled to have access to the microphone.

1. In the main Sound setup window, click the "Microphone privacy settings."

) Home	Sound	
Find a setting	Output Choose your output device	Related Settings Baseboth and other devices Securit Control Panel
Cisplay	Headphones (3- ATR2500e-US8 V Centilin apps may be set up to use different sound devices than the one selected here. Outsonize app volumes and devices in advanced sound options.	Microphone grinacy settings Ease of Access audio se
Notifications & actions Focus assist O Power & sleep	Device properties Master volume d0	Have a question? Set up a microphone Fix sound problems Get tells
Battery Storage	A Troublishoot Manage sound devices	Make Windows better Give us feedback
Tablet mode Multitasking	Input Choose your input device Microphone (J- ATR2500r-USB M.,	
Projecting to this PC Shared experiences	Certain apps may be set up to use different sound devices than the one selected here. Outcomize app volumes and devices in advanced sound options.	
Clipboard	Test your microphone	
() About	Manage sound devices	

The Privacy settings window for the microphone opens. Verify that the "Allow apps to access your microphone" switch is set to "On."

⊛ H	ome	Microphone		
Find	a setting P	Allow access to the micropho	ne on this device	Know your privacy options
Privacy	,	If you allow access, people using this d if their apps have microphone access b page. Denying access blocks Windows apps, and most desktop apps from acc	levice will be able to choose y using the settings on this features. Microsoft Store essing the microphone.	Learn how this setting impacts yo privacy. Learn more Privacy dashboard Discord statement
Windo	ws permissions	Microphone access for this device is or	1	rinky Making
A G	eneral	Change Dr		Have a question? Get help
Ri 28	seech	Allow appr to access your mi	rrophone	
8.0	king & typing personalization	If you allow access, you can choose wh	ich apps can access your	Make Windows better
R D	agnostics & feedback	microphone by using the settings on the blocks apps from accessing your micro	his page. Denying access phone.	Give us feedback
의 사	ctivity history	- 0n		
App pe	ermissions	Some deskto and may still be able to when settings in the age are off. Fin	access your microphone d out why	
≜ lo	cation	If an app is using your mit, seene, yo	u'll see this icon: 🖡	
(C) C4	strera			
Şм	krophone	Choose which Microsoft Stor your microphone	eps can access	
₿ ve	pice activation	Some apps need to access your microp Turning off an app here might limit wh	ohone by the as intended. at it can do	
Q N	otifications	3D Viewer	⊃ or	
AT A:	ccount info	Camera	on	
H ^R Co	ontacts	Cadara		
	dandar	O		

Advanced setup with Windows 10 (continued)

3. Scroll down to make certain the apps you want to use the microphone with are enabled. If not use the switch slider associated with the app to turn it on.



4. Scroll down to the section "Allow desktop apps to access your microphone" and verify that the switch is turned on. This allows applications such as Audacity to have access to the microphone (or other chosen audio source).



Additional Information

Using headphones

The ¹/e" (3.5 mm) headphone jack on the bottom of the microphone allows you to directly monitor your recording with a pair of headphones. When your preliminary setup is completed, and your USB microphone is connected to your computer's USB port (the microphone's blue LED is illuminated), plug your headphones into the headphone jack on the bottom of the microphone. While talking into the microphone, you should hear yourself in the headphones. Adjust the volume up or down by rotating the Up/ Down dial on the bottom of the microphone level.

Selecting software

You have many choices in recording software. Audacity, available for free online at http://audacity.sourceforge.net/, is a widely used software program that provides basic recording software.

Setting your software levels

Correct adjustment of microphone level is important for optimum performance. Ideally, the microphone level should be as high as possible without overloading the input of your computer. If you hear distortion, or if your recording program shows levels that are consistently overloaded (at peak levels), turn the microphone volume (or level) down, either through your control panel (or system preferences) settings, or through your recording software. If your recording program shows insufficient level, you can increase the microphone gain either from the control panel (or system preferences) settings or through your recording program.

No further microphone level adjustments should be needed, as long as the acoustic input does not change significantly.

Positioning your microphone

It is important to position the microphone directly in line (on axis) with the person speaking/singing or instrument (or other sound source) to achieve the best frequency response of the microphone.

For use in speaking/singing applications, the ideal placement for the microphone is directly in front of the person speaking/singing. The same placement is optimal when miking an instrument such as an acoustic guitar, drums or piano. Experiment with different mic placements to find the best sound for your particular setup.

XLR operation

For live-sound applications, connect the XLRF connector of the included XLR cable to the XLRM output on the bottom of the microphone; connect the cable's XLRM connector to a standard XLRF microphone input on your mixer. Turn the microphone's ON/OFF switch to the "ON" position. Set the microphone's level by following the instructions included with your mixer. **Note:** The ON/OFF switch does not affect the LED.

Protecting your microphone

Take care to keep foreign particles from entering the windscreen. An accumulation of iron or steel filings on the diaphragm, and/or foreign material in the windscreen's mesh surface, can degrade performance.

ATR2100x-USB Specifications⁺

Element: Dynamic Polar Pattern: Cardioid Frequency Response: 50 – 15,000 Hz Power Requirements: USB Power (5V DC) Bit Depth: Up to 24 bit Sample Rate: 44.1 kHz/48 kHz/96 kHz/192 kHz Controls: On/off switch; headphone volume control Weight: 268 g (9.5 oz) Dimensions: 183.0 mm (7.20") long, 51.0 mm (2.01") maximum body diameter Output Connector: USB-C/XLR Headphone Output Power: 10 mW @ 16 ohms Headphone Jack: 3.5 mm TRS (stereo)

Accessories Included: Stand clamp for 5/4"-27 threaded stands, tripod desk stand, 2 m (6.6') USB-C to USB-C cable (USB On-The-Go Compliant), 2 m (6.6') USB-C to USB-A cable, 3 m (9.8') XLRF to XLRM cable

System Requirements: Macintosh: Mac OS X; USB 1.0 or 2.0; 64 MB RAM (minimum) Windows: Windows 7/8/10; USB 1.0 or 2.0; 64 MB RAM (minimum)

th the interest of standards development, A.T.U.S. offers full details on its test methods to other industry professionals on request. Specifications are subject to change without notice.

Frequency Response



Polar Pattern



ATR2100x-USB U.S. Lifetime Limited Warranty

This product is warranted in the U.S.A. by Audio-Technica U.S., Inc. (A.T.U.S.) for the lifetime of the original purchaser. During the warranty period, A.T.U.S. will repair or replace these products, provided they are sent prepaid to the address below, with proof of original purchase and \$15.00 for handling and return to a U.S. address. Check or money order required; no cash or stamps. A.T.U.S. reserves the right to replace any product with one of equal value.

Except to the extent precluded by applicable state law, A.T.U.S. will have no liability for any consequential, incidental, or special damages; any warranty of merchantability or fitness for particular purpose expires when this warranty expires. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

Outside the U.S.A., please contact your local dealer for warranty details.

Register your product at audio-technica.com

Audio-Technica U.S., Inc. 1221 Commerce Drive, Stow, Ohio 44224 USA



Audio-Technica Corporation (Headquarters) 2-46-1 Nishi-naruse, Machida, Tokyo, 194-8666, Japan

Audio-Technica U.S., Inc. 1221 Commerce Drive, Stow, Ohio, 44224, USA

www.audio-technica.com © 2019 Audio-Technica Corporation P52830 CE