



Hepburn^{MK}

Operation Guide



Guide d'utilisation
Betriebsanleitung

Guía de funcionamiento
Guia de Operação

Gebruiksaanwijzing
Bruksanvisning





Welcome To VQ

VQ is a unique British brand inspired by the fusion of Sound and Style.

At VQ we believe that colour and design is an important part of who we are, so why should the technology we buy only be Black or Silver and lacking individuality of design?

Our award winning acoustic development programme ensures all our products feature the latest technology and unbeaten sound quality. Couple this with our passion for the creative world of: the arts, fashion & interior design and this means our products don't just sound great, they look great too.

So thank you for joining the VQ Revolution with our award winning technology that's designed to match your style.

We encourage you to fall in love with VQ and your new Hepburn Mk II.

Jonathan Merricks
CEO & Creative Director

Daniel Copley
Product Designer



Bardot

DAB/DAB+ • FM • Bluetooth





Christie

DAB/DAB+ • FM • Bluetooth



An Iconic design which embodies our Sound & Style mission
DAB / DAB+ / FM Radio Reception
Bluetooth Connectivity
Award winning British Speaker Technology

Classic design, modern functionality
DAB / DAB+ / FM Radio Reception
Bluetooth & NFC Connectivity
Optional Rechargeable Battery Pack & Carry Case





Retro Mk II

DAB/DAB+ • FM • Apple Lightning Dock



Retro Mini

DAB/DAB+ • FM • Bluetooth



Our classic, with retro style and modern function
DAB / DAB+ / FM Radio Reception
Apple docking Lightning for connector devices
Bluetooth Connectivity

Our classic style made fabulously miniature in a range of colours and designs
DAB / DAB+ / FM Radio Reception
Bluetooth Connectivity





The VQ Colour Range

BLACK

BROWN

CREAM

RED

MUSTARD

EMERALD

TEAL

BLUE

RADIANT ORCHID

HOT PINK

PURPLE

Emma Bridgewater Pattern Range 2015/16

POLKA DOT

BLUE DAISY

SAMPLER

ROSE & BEE

WALLFLOWER

BLACK TOAST

MARMALADE



Hepburn ^{Mk II}
 DESIGNED FOR INDIVIDUAL TASTE AND STYLE



Contents

Welcome to VQ 3

If You Love Hepburn Mk II... You'll Love... 4

The Benefits of Digital Radio 12

Your VQ Hepburn Mk II - Born in Britain 13

Finding Your Way Round Your Hepburn Mk II 14

Introducing your Hepburn Mk II Bluetooth Speaker, DAB/DAB+ and FM Radio 17

 Hepburn Mk II: compatible, stylish, hassle-free 17

 What can my Hepburn Mk II do apart from look fab? 18

Getting Started 20

 Positioning your Hepburn Mk II 20

 Adjusting the Aerial 20

 Turning the Unit On and Off 20

 Volume Control 20

 Using DAB Mode 20

 Setting Dynamic Range Control (DRC) 22

 Using FM Mode 23

 Setting Station Presets for DAB and FM 24

 Using Smart Device Mode with Bluetooth Devices 25

 Using Auxiliary Input Mode 26

 General Settings 27

VQ Battery Pack (optional)..... 29

Important Safety & Environmental Information 30

Specification 32

Support 33



The Benefits of Digital Radio

When you upgrade to digital radio you get more choice than ever before – with your existing favourite stations just waiting to be experienced in digital quality but also a plethora of new digital-only stations featuring all kinds of; music, chat and programming you'll love.

Digital radio is not just about choice, it's about quality – with digital broadcasts you'll hear everything in crystal clear clarity.

If you have any concerns about the digital coverage in your area – you can check your signal on the UK Digital Radio website, it's completely free and totally impartial – www.ukdigitalradio.com



DIGITAL RADIO

Your VQ Hepburn Mk II - Born In Britain


You can be proud of your Hepburn Mk II and rely on its quality as it's designed and engineered in Britain featuring British acoustic development.

At VQ we're proud to be British and we're proud to take our inspiration from quintessential British areas of excellence - Design, Fashion, Music and The Arts.

It's our aim to take these inspirations and create our own unique sense of Sound & Style – but also to share these influences with you to inspire your own sense of style.




Finding Your Way Around Your Hepburn Mk II



- 1. **- VOLUME + knob** Turn to adjust volume level.
- 2. **POWER button** Press to switch between standby and active modes.
- 3. **SOURCE button** Press to switch between DAB, FM, Smart Device and Auxiliary Input modes.
- 4. **PAIR button** Press to select Bluetooth device for pairing in Smart Device mode.
- 5. **SKIP button** Press to skip to next track in Smart Device mode. Press and hold to fast forwards current track in Smart Device mode. Continues through next tracks if held.
- 6. **PLAY/PAUSE button** Press to switch between pause/play of current track in Smart Device mode.
- 7. **BACKWARD button** In Smart Device mode, press to return to start of current track if more than 2.5 seconds in, otherwise skip to previous track. Press and hold to rewind current track in Smart Device mode. Continues through previous tracks if held.
- 8. **LCD display**
- 9. **SNOOZE button** Press to change the backlight level. When alarm is sounding, press to activate Snooze feature.
- 10. **ALARM button** Press to turn Alarms on or off.
- 11. **MENU button** Press to display menu options relevant to current mode.
- 12. **EQ button** Press to select or design Equaliser.
- 13. **INFO button** Press to view station information.
- 14. **PRESETS button** Press and hold to save preset stations; Press to recall a saved preset station.
- 15. **-TUNING+ knob** Turn to tune and press to confirm.

Back View



- 1. Aerial
- 2. USB port for charging devices
Outputs 5V volts for charging personal devices such as your phone or MP3 player.
- 3. DC-IN power cable input
- 4. AUX-IN for other devices
- 5. Headphone Out



Introducing your Hepburn Mk II Bluetooth Speaker, DAB/DAB+ and FM Radio

Hepburn Mk II: compatible, stylish, hassle-free

We've designed your Hepburn Mk II to make compatibility problems a thing of the past.

Compatible with your devices – old and new.

Hepburn Mk II's Bluetooth lets you wirelessly connect the latest smart phones, tablets, MP3 players and other Bluetooth-enabled devices. Other audio devices without Bluetooth like turntables, computers or older phones can plug in to the 3.5mm jack.

Compatible with radio stations all over the world.


Enjoy the ever increasing selection of digital broadcasts with Hepburn Mk II's DAB/DAB+ receiver as well as your old favourites with the FM tuner. Never lose track of any of your favourite stations with 30 station presets. For useful information about DAB in the UK, websites such as www.ukdigitalradio.com feature handy postcode finders that will tell you which DAB channels are available in your area.

Ready to deliver your ideal sound.

As well as providing eight preset equaliser profiles, Hepburn Mk II lets you design one of your own to exactly match your current desires.

Right for you.

Exciting colours and design complement your personal taste and style.



What can my Hepburn Mk II do apart from look fab?

Here's a brief run-down of your Hepburn Mk II's capabilities. Everything is explained fully later in this guide.

Bluetooth speaker

Lets you play audio from a Bluetooth source like a phone or mp3 player, and lets you control the playback from your Hepburn Mk II. The tracks on your phone will never have sounded so good.

DAB/DAB+ receiver

Digital Audio Broadcasting (DAB) is the next big thing in radio. Clarity, station choice and ease of tuning are often cited as benefits. There are two versions, DAB and DAB+. Your Hepburn Mk II works with either.

FM Radio

DAB isn't everywhere, so there's an FM radio in your Hepburn Mk II so that you can still listen to radio wherever DAB is not available.

Auxiliary connection

Lets you plug in and listen to an external audio source that doesn't do Bluetooth, so your older devices aren't left out.

Phone Charger

When plugged in to the mains your Hepburn Mk II can charge a suitable phone or music player using its built-in USB connector. Convenient, and saves a power socket.

Dual Alarms

Wake up to your favourite radio station – or the buzzer.

Countdown Timer

A cooking timer with a range of up to 99 minutes makes your Hepburn Mk II even more useful in the kitchen.



Getting Started

Carefully remove your Hepburn Mk II from its box. You may wish to store the packaging for future use. Inside the box you will find:

- Your Hepburn Mk II
- Power Adapter with plugs for UK and mainland Europe
- Quick Start Guide

Positioning your Hepburn Mk II

Place your Hepburn Mk II on a flat / stable surface, with reference to the safety information section in this manual.

Adjusting the Aerial

The aerial should be extended to ensure you receive the best signal possible in both DAB and FM radio modes. Later on it may be necessary to alter the position of your Hepburn Mk II and its aerial to achieve the best reception.

Turning the Unit On and Off

1. Connect the plug at the end of power adapter cable to the DC in jack on the back of your Hepburn Mk II. Insert the power adapter into the mains socket.
2. Turn the mains power on and then press the POWER button to turn on the unit.

Pressing the POWER button again switches your Hepburn Mk II to standby mode. To switch the unit off completely, unplug the power adapter from the mains socket.

Volume Control

Adjust the radio volume by turning the - VOLUME + knob.

Using DAB Mode

Note: When you turn on the radio it will automatically search and store all the available stations. You should conduct an additional Full Scan to ensure all stations are picked up and stored. It is also recommended every few months to run a new scan to pick up any new DAB/ DAB+ stations that may have begun broadcasting after purchasing your Hepburn Mk II.

1. Repeatedly press the SOURCE button until DAB is shown on the display. For the first time your Hepburn Mk II will carry out a full scan and store a list of stations in memory.



- Once the scanning is complete the DAB/DAB+ stations will be displayed in alphanumeric order. The first station in the list will be selected.

Note: if no DAB/DAB+ signal is found in your area, it may be necessary to relocate your radio to a stronger signal area. Websites such as www.ukdigitalradio.com in the UK feature handy postcode finders that will tell you what DAB channels you can expect to receive.

Selecting another DAB/DAB+ Station


While a program is playing, turn the -TUNING+ knob to cycle through available stations, and then press the -TUNING+ knob to confirm the station you want to play.

Updating the Stations List

Press the MENU button, turn the -TUNING+ knob to select Full scan, and then press the -TUNING+ knob to confirm. Scan will commence.

Displaying Signal Strength

While playing a DAB/DAB+ program, repeatedly press the INFO button until the display shows a signal bar indicating the strength of the current station.



The indicator on the signal bar shows the minimum acceptable signal level.

Note: Stations with signal strength below the minimum signal level may not provide steady audio.

Manual Tuning

- Press the MENU button, turn the -TUNING+ knob to select Manual tune, and then press the -TUNING+ knob to confirm. The display will show the channel number and frequency.
- Turn the -TUNING+ knob to step through the channels and then press the -TUNING+ knob to select the current channel.

Note: If there is a multiplex corresponding to this channel and frequency, then after a few seconds the display will show a tuning meter with the signal strength and the multiplex.

- To exit manual tune, press the -TUNING+ knob again.

Setting Dynamic Range Control (DRC)

You can set the compression level of stations to eliminate the differences in dynamic range or sound level between radio stations. If loud stations are too loud while quiet stations are too quiet, DRC may help.

Note: DRC off indicates no compression

DRC low indicates little compression

DRC high indicates maximum compression

- Press the MENU button, turn the -TUNING+ knob to select DRC, and press the -TUNING+ knob to confirm.
- Turn the -TUNING+ knob to select 'DRC high', 'DRC low' or 'DRC off', and then press the -TUNING+ knob to confirm your setting.

Changing Station Display Order

You may want to display your stations in a different order. Your options are:

- Alphanumeric: Display all stations in alphanumeric order.
- Ensemble: List currently broadcasting active stations before inactive ones.
- Valid: Remove inactive stations from the station list.

- Press the MENU button, turn the -TUNING+ knob to select Station order, and then press the -TUNING+ knob to confirm.
- Turn the -TUNING+ knob to select 'Alphanumeric', 'Ensemble' or 'Valid', and then press the -TUNING+ knob to confirm your selection.

Pruning Your Station List

This feature enables your radio to remove inactive stations from the station list.

- Press the MENU button, turn the -TUNING+ knob to select Prune, and then press the -TUNING+ knob to confirm.
- Turn the -TUNING+ knob to 'Yes', and then press the -TUNING+ knob to confirm.

Viewing Station Information

To view currently playing station information, press the INFO button repeatedly to cycle through DLS (Dynamic Label Segment), Signal Strength, Program Type, Ensemble, Program Frequency, Signal Quality, Bitrate, Codec and Time and Date.



Using FM Mode

Selecting FM Mode

1. Press the SOURCE button repeatedly until FM is displayed.
2. On first use the display will show 87.50MHz, the start of the FM frequency range. Otherwise, the last listened-to FM station will be selected.

87.50MHz
[No RadioText]

Scanning for FM Stations

1. To manually scan FM stations, while frequency is displayed, turn the -TUNING+ knob clockwise/ anticlockwise to increase/decrease frequency by 0.05MHz per step.
2. To automatically scan, turn the -TUNING+ knob clockwise or anticlockwise and then press the -TUNING+ knob.
Your Hepburn Mk II will scan forwards or backwards until it reaches the next available station. To scan forwards, turn the -TUNING+ knob clockwise before pressing it. To scan backwards turn the -TUNING+ knob anticlockwise before pressing it.

Setting Scan Preferences

By default, FM scans stop at any available station. This may result in tuning to a weak station, resulting in poor sound quality. Your Hepburn Mk II helps you avoid weak stations.

1. To change the scan settings to stop only at stations with good signal strength, press the MENU button, turn the -TUNING+ knob to select Scan Setting, and then press the -TUNING+ knob to confirm.
2. Turn the -TUNING+ knob to select 'Strong stations only', and press the -TUNING+ knob to confirm your selection.

Forcing mono for weak stations

By default, all stereo stations are reproduced in stereo. For weak stations, this may result in poor sound quality. Your Hepburn Mk II can offset this effect by playing weak stations in mono.

1. To play weak stations in mono, press the MENU button, turn the -TUNING+ knob to select Audio setting, and then press the -TUNING+ knob to confirm.
2. Turn the -TUNING+ knob to select 'Forced mono' and press the -TUNING+ knob to confirm.

Viewing Station Information

A variety of station information is transmitted by broadcasters, and your Hepburn Mk II offers a convenient way for you to view it.

To view currently playing station information, press the INFO button repeatedly to cycle through Radio Text, Program Type, PS, Audio Info and Time and Date.

Setting Station Presets for DAB and FM

Storing Preset Stations

You can store up to both 30 DAB and FM stations as preset stations. This lets you access your favourite stations quickly and easily.

1. While your favourite station is playing, press and hold the PRESETS button until the display shows:

Preset Store
< 1: (Empty) >

If you have stored presets, their details will be displayed instead of 'EMPTY':

2. Turn the -TUNING+ knob to cycle through preset numbers 1-30. Find an empty preset, or one you wish to replace.
3. Press the -TUNING+ knob and your station will be stored as that preset number.

Recalling a Preset Station

- 1 Press the SOURCE button to select the mode you wish to play: FM or DAB.
2. Press the PRESETS button to show the saved preset stations.

Preset Recall
< 1: BBC1 >

3. Turn the -TUNING+ knob to find the preset station you want to play, then press the -TUNING+ knob to confirm.



Using Smart Device Mode with Bluetooth Devices

Your Hepburn Mk II lets you play and control Bluetooth devices. To let this happen the devices have to be paired.

Pairing your Hepburn Mk II with a Bluetooth device


1. Press the SOURCE button repeatedly to select Smart Device mode.
2. After two seconds the display will show "Waiting BT Connection".
3. Activate your Bluetooth device and select the search mode.
4. "Hepburn Mk II" will appear on your Bluetooth device.
5. Select "Hepburn Mk II" and enter "0000" for the password if necessary.
6. "Connect Success will show on the display when connection is successful.



Connect Success

Connecting to an already paired Bluetooth device

1. Press the PAIR button. If there are any devices paired with your Hepburn Mk II, the first one will show on the display.



Switch to 1:
Smart Device

2. Turn the -TUNING+ knob to cycle through the list of paired devices, then press the -TUNING+ knob to select the displayed device.
3. The display will show "Waiting BT Connection". Select "Hepburn Mk II" on your Bluetooth device.
4. "BT Connected" and the device name will show on the display when connection is successful.

Controlling your Bluetooth device with your Hepburn Mk II

Skip back, Play/Pause and Skip forward buttons can control a Bluetooth device connected to your Hepburn Mk II.

Using Auxiliary Input Mode

Auxiliary Input allows for a quick and easy connection to an MP3 player or other external audio source. You need an audio cable with a 3.5mm jack (not supplied) to connect to your Hepburn Mk II.

1. Before connecting to the mains socket, connect your external audio device to the AUX IN socket on the rear of your Hepburn Mk II.
2. Connect the power adapter to the mains socket, press the POWER button to switch your Hepburn Mk II on.
3. Press the SOURCE button repeatedly until Auxiliary Input appears on the display.



Auxiliary Input

In this mode, you control your audio device through its own controls. Volume levels on both the audio device and your Hepburn Mk II may need to be adjusted for optimal volume and clarity.



General Settings

Equaliser

Your Hepburn Mk II has seven equalisation settings to suit different sound types, and you can also configure one of your own to exactly match your requirements. Each of the equalisation settings will change the tone of your Hepburn Mk II when selected. To choose an equalisation setting:

1. Press the EQ button to select 'Equaliser'.
2. Turn the - TUNING + knob and then press it to select Normal, Classic, Jazz, Pop, Rock, Speech, Bass or My EQ.
3. To set up your own Equaliser profile, select 'My EQ', and then set the level of Treble, Bass and Loudness using the - TUNING + knob.

Count Down Timer (Cooking Timer)

The timer can be set at one minute intervals up to 99 minutes in the future.

1. Press the MENU button, and then turn the - TUNING + knob to select System menu. Press the - TUNING + knob to confirm.
2. Turn the - TUNING + knob to select Count Down Timer menu, and then press the - TUNING + knob to confirm.
3. Turn the - TUNING + knob until the desired time appears in the display, then press the - TUNING + knob to confirm.
4. To view the remaining time, follow steps 1-2 to select Count Down Timer menu again.
5. When the time is elapsed, the buzzer will sound, at an increasing volume. Any other sound playing on your Hepburn Mk II will be muted while the buzzer is sounding.
6. Press the - TUNING + knob to stop the buzzer. Otherwise the buzzer will turn off automatically after 30 minutes.
7. To cancel an already set Count Down timer, follow steps 1-3 to set the time to 00:00 minutes.

Time and Date

Your Hepburn Mk II can set its time and date from DAB, or you can set it manually. You can also select your date and time formats.

1. Press MENU, turn the - TUNING + knob to display Time then press the - TUNING + knob to select.

Further turning of the - TUNING + knob will cycle through the options below:

Set Time/date:	Manually set-up both Time and Date
Auto update:	'Update from DAB' or 'No update'
Set 12/24 hour format:	'Set 24 hour' or 'Set 12 hour'
Set date format:	'DD-MM-YYYY' or 'MM-DD-YYYY'

2. Use the - TUNING + knob to find and select the options you prefer.

To set time manually:

1. Select "Set Time/Date"
2. Turn the - TUNING + knob to select correct hours, press the - TUNING + knob to confirm.**
3. Turn the - TUNING + knob to select correct minutes, press the - TUNING + knob to confirm.
4. Turn the - TUNING + knob to select correct day, press the - TUNING + knob to confirm.*
5. Turn the - TUNING + knob to select correct month, press the - TUNING + knob to confirm.*
6. Turn the - TUNING + knob to select correct year, press the - TUNING + knob to confirm.

**The value of this item is affected by your hour format setting

*The order of these items are affected by your date format setting.

Alarms

Your Hepburn Mk II provides highly flexible dual alarms. Before setting your alarms, please set the time and date as detailed in the previous section. Then:

1. Press the ALARM button repeatedly to select 'Alarm 1 Setup' or 'Alarm 2 Setup' and press the - TUNING + knob to confirm. This will start the Alarm Wizard.
2. The Alarm Wizard will step you through the alarm options. Turn the - TUNING + knob to select options, and then press the - TUNING + knob to confirm the settings and move to the next option.
(To cancel alarm setup, press ALARM button again.)

Options are as follows:

Alarm states:	On or Off
Alarm time:	00:00 (manually set up the time)
Alarm duration time:	15/30/45/60/90 mins
Alarm source:	DAB, FM or buzzer (If you select DAB or FM, you can choose your last listened to station, or Preset 1, if set)
Alarm active day:	Daily, Once, Weekends or Weekdays
Alarm volume:	Turn the - TUNING + knob to adjust the alarm volume

3. When the display shows 'Alarm Saved', the alarm setting is set.
4. To temporarily switch off alarm, press the SNOOZE button when the alarm is sounding. Press the SNOOZE button repeatedly to set Snooze period time of 5, 10, 15 or 30 minutes in turn. The selected snooze time will show as "Snooze mm : ss" on the display.
Note: Different Snooze periods are available depending on alarm duration.
5. To turn off the Alarm, press the POWER or ALARM buttons when the alarm is sounding.



6. To cancel Alarm, refer to steps 1-3 to set Alarm states to 'Off'.

Backlight Level

To change the backlight level of standby mode and power on mode, press SNOOZE repeatedly while alarm is not sounding. Or using the menu:

1. Press the MENU button and then turn the - TUNING + knob to select System menu. Press the - TUNING + knob to confirm.
2. Turn the - TUNING + knob to select Backlight menu and press the - TUNING + knob to confirm.
3. Turn the - TUNING + knob to select backlight level, and press the - TUNING + knob to confirm the setting.

Power On - High
Medium
Low

Standby - High
Medium
Low

Language

1. Press the MENU button, and then turn the - TUNING + knob to select System menu. Press the - TUNING + knob to confirm.
2. Turn the - TUNING + knob to select Language menu and press the - TUNING + knob to confirm.
3. Turn the - TUNING + knob to select language and press the - TUNING + knob to confirm.

Factory Reset

Factory reset resets all user settings to default values, so time/date, alarm settings, presets and Bluetooth settings are lost.

1. Press the MENU button, turn the - TUNING + knob if necessary to select System menu and press the - TUNING + knob to confirm. Then turn the - TUNING + knob to select Factory Reset. Press the - TUNING + knob to confirm.
2. Turn the - TUNING + knob to 'Yes', and then press the - TUNING + knob to confirm. Display will show "Restarting" and your Hepburn Mk II will reset to Factory settings.

Software Version

Note: The helpdesk may ask you for the software version of your product.

1. Press the MENU button, and then turn the - TUNING + knob to select SW Version. Press the - TUNING + knob to confirm. Display will show "SW Version" and below it your Hepburn Mk II's software version, scrolling as necessary.

VQ Battery Pack (optional)

- The VQ Battery Pack is an optional accessory which enables the portable use of your Hepburn Mk II
- The VQ Battery Pack is designed for a long life and will provide charge and recharge function for several years with responsible use.
- The VQ Battery Pack is available to purchase directly from VQ (www.MyVQ.com) or from a range of retailers.
- Should you need to dispose of a VQ Battery Pack ensure you recycle or dispose of the pack in an environmentally friendly way, as recommended by your own regional regulations.
- Do not short circuit batteries or throw them into water, general rubbish or in a fire.

Installing VQ Battery Pack

1. Switch Hepburn Mk II off and disconnect from the mains power supply.
2. Open the battery compartment.
3. Insert the VQ Battery Pack connector plug into the socket in the compartment. Line up the ridges on the plug with the slots in the socket to ensure correct orientation. Do not force the plug.
4. Insert VQ Battery Pack into the battery compartment, logo side out.
5. Replace the battery cover and connect Hepburn Mk II to the mains.
6. The VQ Battery Pack will begin charging.

Note: If you are charging the VQ Battery Pack for the first time or after an extended period of inactivity it is recommended that it is charged for around 24 hours to ensure full battery power. If the VQ Battery Pack is flat there may be a slight delay before the battery charging indicator is displayed.

Note: VQ Battery Pack is sold separately

**Important Safety Information – please read**

Please read this guide before using your unit – it contains guidance and recommendations that can help ensure long-lasting, trouble-free, safe operation. Please keep this guide for future reference.

Be careful. Avoid:

- **Liquids:** don't expose your unit to drips or splashes, and don't put liquid containers like vases on it or near it.
- **Humidity or moisture:** humid or moist places like bathrooms and steam rooms need specially-designed equipment.
- **Heat:** don't expose your unit to direct sunlight or heat from radiators or other heat sources. Audio/video devices can generate a lot of heat; don't put your unit on top of such devices. Don't use naked flames anywhere near your unit either.
- **Dust and restricted airflow:** make sure your unit is in free-flowing air to avoid overheating.
- **Vibration:** constant vibration can cause damage.
- **Extreme climates:** this unit is designed for operation in moderate climates.

IMPORTANT:

- **DO NOT** listen at high volume: High volumes can permanently damage hearing.
- **DO NOT** use equipment, especially headphones, when it could distract you from the requirements of traffic or other safety.
- **DO NOT** Use equipment that is not working normally or you suspect may be faulty or damaged.
- **DO NOT** leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation. Switch off using the switch on the equipment and make sure that your family knows how to do this. Special arrangements may need to be made for infirm or handicapped people.

Always:

- Operate all controls as instructed in the manual.
- Ensure that all electrical connections (including the mains plug, extension leads and inter-connections between the pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug before making or changing connections.



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK), NO USER SERVICEABLE PARTS INSIDE, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



DANGEROUS VOLTAGE Dangerous Voltages, that may be of sufficient magnitude to constitute a risk of electric shock to persons is present within this product's enclosure.



ATTENTION The owner's manual contains important operating and maintenance instructions, for your safety, it is necessary to refer to the manual.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO DRIPPING OR SPLASHING.

Note: This unit will become warm when used for a long period of time. This is normal and does not indicate a problem with the unit.

Battery safety guidelines

- Be sure to insert batteries of the correct type and ensure correct polarity (+/-).
- To insert batteries, remove the battery compartment cover and insert batteries observing polarity.
- Ensure the cover is secure and remove batteries in a safe manner without the use of metallic or other conductive objects
- Batteries should not be replaced by children
- Never dispose of batteries in fire as they may explode
- Batteries should not be exposed to excessive heat such as sunshine, fire or naked flame.
- Only use batteries of the same type
- Do not mix old and new batteries and do not mix alkaline and rechargeable batteries
- Do not attempt to charge non-rechargeable batteries
- If the radio is not going to be used for a long period of time, remove the batteries from the battery compartment
- Always remove spent batteries from the battery compartment and dispose of them responsibly to protect the environment

Note: For battery operation, please switch off the mains adaptor and remove the mains power plug from the back of the radio.'



Specification

Description:	Bluetooth Speaker with DAB/DAB+ and FM digital radio
Frequency Ranges:	FM: 87.5-108MHz
DAB/DAB+:	174.928 – 239.200MHz
Power Supply:	AC Power Input: 100-240VAC, 50-60Hz
Audio Output:	80Hz- 20KHz frequency range
Power Consumption:	10W rms
Dimensions:	285mm x 75mm x 155mm



This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end of its life separately from your household waste. There are separate collection systems for recycling in the EU.

For more information, please contact the local authority or your retailer where you purchased the product.

VQ hereby declares that the Hepburn Mk II radio is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

For further details, please contact :

VQ
9-10 Mill Lane
Alton
Hampshire
GU 34 2QG
support@myvq.com
www.MyVQ.com



Support

We're sure you're going to have a long and happy relationship with your new Hepburn Mk II. How can we be so sure, well, we've designed, engineered and loved this product from the pages of a concept book through to the gorgeous product you have in your hands. We're very proud of our products and the care and attention we give them, this is reflected in our fantastically low returns rate.


However, if you do have a problem then we're always happy to help:



0333 1234 601




support@myvq.com



If You Love Your Hepburn Mk II Let The World Know

We take great pride in all our products and we hope you love your Hepburn Mk II, if you do we'd love to hear about it. So why not share your experience and your own sense of sound & style with us via social media or reviews with our retailers.


#MyVQ





SHOW US YOUR

Sound & Style

#MyVQ

 /MyVQUK

 @MyVQUK

 @MyVQUK

 /MyVQUK